NAME

INSTALL — Installation procedure for NetBSD/sandpoint.

CONTENTS

DESCRIPTION

About this Document

This document describes the installation procedure for NetBSD 5.1.2 on the *sandpoint* platform. It is available in four different formats titled `INSTALL.`*ext*, where *.ext* is one of `.ps`, `.html`, `.more`, or `.txt`:

- `.ps` PostScript.
- `.html` Standard Internet HTML.
- `.more` The enhanced text format used on UNIX-like systems by the `more`(1) and `less`(1) pager utility programs. This is the format in which the on-line *man* pages are generally presented.
- `.txt` Plain old ASCII.

You are reading the *PostScript* version.

What is NetBSD?

The NetBSD Operating System is a fully functional Open Source UNIX-like operating system derived from the University of California, Berkeley Networking Release 2 (Net/2), 4.4BSD-Lite, and 4.4BSD-Lite2 sources. NetBSD runs on 57 different system architectures (ports) across 15 distinct CPU families, and is being ported to more. The NetBSD 5.1.2 release contains complete binary releases for many different system architectures. (A few ports are not fully supported at this time and are thus not part of the binary distribution. Please see the NetBSD web site at **http://www.NetBSD.org/** for information on them.)

NetBSD is a completely integrated system. In addition to its highly portable, high performance kernel, NetBSD features a complete set of user utilities, compilers for several languages, the X Window System, firewall software and numerous other tools, all accompanied by full source code.

NetBSD is a creation of the members of the Internet community. Without the unique cooperation and coordination the net makes possible, it's likely that NetBSD wouldn't exist.

Dedication

NetBSD 5.1.2 is dedicated to the memory of Yoshihiro Masuda, who passed away in May 2011.

He was a spiritual pillar of the BSD community in Japan. Through an impressive number of books and articles on BSD, he gave courage to BSD developers. We remember his passion and deep love for BSD.

Changes Between the NetBSD 5.1 and 5.1.2 Releases

NetBSD 5.1.2 is the second critical/security update of the NetBSD 5.1 release branch. It represents a selected subset of fixes deemed critical for security or stability reasons.

Please note that all fixes in security/critical updates (i.e., NetBSD 5.0.1, 5.0.2, etc.) are cumulative, so the latest update contains all such fixes since the corresponding minor release. These fixes also appear in minor releases (i.e., NetBSD 5.1, 5.2, etc.).

The complete list of changes can be found in the CHANGES-5.1.2:

http://ftp.NetBSD.org/pub/NetBSD/NetBSD-5.1.2/CHANGES-5.1.2

file in the top level directory of the NetBSD 5.1.2 release tree. Note that since 5.1.1 was not announced, the changes below are relative to 5.1, not 5.1.1. An abbreviated list is as follows:

Security Advisory Fixes

- NetBSD-SA2010-012: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2010-012.txt.asc
  OpenSSL TLS extension parsing race condition.
- NetBSD-SA2011-001: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-001.txt.asc
  BIND DoS due to improper handling of RRSIG records.
- NetBSD-SA2011-002: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-002.txt.asc
  OpenSSL TLS extension parsing race condition.
- NetBSD-SA2011-003: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-003.txt.asc
  Exhausting kernel memory from user controlled value.
- NetBSD-SA2011-004: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-004.txt.asc
  Kernel stack overflow via nested IPCOMP packet.
- NetBSD-SA2011-005: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-005.txt.asc
  ISC dhclient does not strip shell meta-characters in environment variables passed to scripts.
- NetBSD-SA2011-006: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-006.txt.asc
  BIND DoS via packet with rrtype zero.
- NetBSD-SA2011-007: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-007.txt.asc
  LZW decoding loop on manipulated compressed files.
- NetBSD-SA2011-008: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-008.txt.asc
  OpenPAM privilege escalation.
- NetBSD-SA2011-009: *,:*
  http://ftp.NetBSD.org/pub/NetBSD/security/advisories/NetBSD-SA2011-009.txt.asc
  BIND resolver DoS.

Advisories prior to NetBSD-SA2010-012 do not affect NetBSD 5.1.2: *.:*

http://www.NetBSD.org/support/security/patches-5.1.2.html

Other Security Fixes

- Fix a buffer overflow in libtelnet.
- OpenSSL: Fix CVE-2010-4180, CVE-2012-0050, CVE-2011-4109, CVE-2011-4109, and CVE-2011-4576.
- Postfix: Update to 2.6.9, fixing CVE-2011-0411.
- dhcpcd: Fix CVE-2011-0996.
- xrdb: Fix CVE-2011-0465.
- `glob`(3): Prevent resource DoS from brace expansion.
- OpenSSH: Fix CVE-2012-0814.

Kernel

- `wapbl`(4): Fix errors that can lead to file system corruption and panics.
- Several stability fixes.

Networking

- Clean up setting ECN bit in TOS. PR 44742.
- Prevent NFS server hang under load. PR 45093.
- `gem`(4): Fix corrupted packet problem on 100Mb/s half duplex links.

Miscellaneous

- Update and add some TNF ssh keys to /etc/ssh/ssh_known_hosts.
- Update tzdata to 2011n.

Known Problems

Using block device nodes (e.g., wd0a) directly for I/O may cause a kernel crash when the file system containing `/dev` is FFS and is mounted with -o log. Workaround: use raw disk devices (e.g., rwd0a), or remount the file system without -o log.

Occassionally, gdb may cause a process that is being debugged to hang when "single stepped". Workaround: kill and restart the affected process.

gdb cannot debug running threaded programs correctly. Workaround: generate a core file from the program using `gcore`(1) and pass the core to gdb, instead of debugging the running program.

The sparc port does not have functional SMP support in this release.

Features to be removed in a later release

The following features are to be removed from NetBSD in the future:

- Support for soft dependencies, also knows as soft updates (see "softdep" in `mount`(8)) will be removed in the next major release.

  NetBSD 5.1.2 includes a preview of WAPBL (Write Ahead Physical Block Logging), which will replace soft dependencies in the next major release. See `wapbl`(4) and
  http://mail-index.netbsd.org/netbsd-announce/2008/12/14/msg000051.html
  for details.

- Support for Xen 2.0.x. The Xen-3 and hypervisor interface is diverging from Xen-2 as development is ongoing, increasing the maintenance cost for NetBSD.

  It should be considered as deprecated. Users are expected to not rely on it any more beyond this major release.

  Further, at least version 3.1 of Xen will be required to run NetBSD as Dom0 or DomU.

The NetBSD Foundation

The NetBSD Foundation is a tax exempt, not-for-profit 501(c)(3) corporation that devotes itself to the traditional goals and Spirit of the NetBSD Project and owns the trademark of the word "NetBSD". It supports the design, development, and adoption of NetBSD worldwide. More information on the NetBSD Foundation, its composition, aims, and work can be found at: **http://www.NetBSD.org/foundation/**

Sources of NetBSD

Refer to **http://www.NetBSD.org/mirrors/**

NetBSD 5.1.2 Release Contents

The root directory of the NetBSD 5.1.2 release is organized as follows:

`.../NetBSD-5.1.2/`

`CHANGES`	Changes between the 4.0 and 5.0 releases.
`CHANGES-5.0`	Changes between the initial 5.0 branch and final release of 5.0.
`CHANGES-5.1`	Changes between the 5.0 and 5.1 releases.
`CHANGES-5.1.1`	Changes between the 5.1 and 5.1.1 releases.
`CHANGES-5.1.2`	Changes between the 5.1.1 and 5.1.2 releases.
`CHANGES.prev`	Changes in previous NetBSD releases.
`LAST_MINUTE`	Last minute changes and notes about the release.
`README.files`	README describing the distribution's contents.
`source/`	Source distribution sets; see below.

In addition to the files and directories listed above, there is one directory per architecture, for each of the architectures for which NetBSD 5.1.2 has a binary distribution.

The source distribution sets can be found in subdirectories of the `source` subdirectory of the distribution tree. They contain the complete sources to the system. The source distribution sets are as follows:

gnusrc This set contains the "gnu" sources, including the source for the compiler, assembler, groff, and the other GNU utilities in the binary distribution sets.

sharesrc This set contains the "share" sources, which include the sources for the man pages not associated with any particular program; the sources for the typesettable document set; the dictionaries; and more.

src This set contains all of the base NetBSD 5.1.2 sources which are not in **gnusrc**, **sharesrc**, or **syssrc**.

syssrc This set contains the sources to the NetBSD 5.1.2 kernel for all architectures as well as the `config`(1) utility.

xsrc This set contains the sources to the X Window System.

All the above source sets are located in the `source/sets` subdirectory of the distribution tree.

The source sets are distributed as compressed tar files. Except for the **pkgsrc** set, which is traditionally unpacked into `/usr/pkgsrc`, all sets may be unpacked into `/usr/src` with the command:

```
# cd / ; tar -zxpf set_name.tgz
```

In each of the source distribution set directories, there are files which contain the checksums of the files in the directory:

`MD5` MD5 digests in the format produced by the command:
cksum -a MD5 *file*.

`SHA512` SHA512 digests in the format produced by the command:
cksum -a SHA512 *file*.

The SHA512 digest is safer, but MD5 checksums are provided so that a wider range of operating systems can check the integrity of the release files.

NetBSD/sandpoint subdirectory structure

The sandpoint-specific portion of the NetBSD 5.1.2 release is found in the `sandpoint` subdirectory of the distribution: `.../NetBSD-5.1.2/sandpoint/`. It contains the following files and directories:

`INSTALL.html`
`INSTALL.ps`
`INSTALL.txt`
`INSTALL.more` Installation notes in various file formats, including this file. The `.more` file contains underlined text using the `more`(1) conventions for indicating italic and bold display.

`binary/`
- `kernel/`
  - `netbsd-GENERIC.gz`
    A gzipped NetBSD kernel containing code for everything supported in this release.
- `sets/` sandpoint binary distribution sets; see below.

`installation/`
- `floppy/` sandpoint boot and installation floppies; see below.
- `misc/` Miscellaneous sandpoint installation utilities; see installation section below.

Binary distribution sets

The NetBSD sandpoint binary distribution sets contain the binaries which comprise the NetBSD 5.1.2 release for sandpoint. The binary distribution sets can be found in the `sandpoint/binary/sets` subdirectory of the NetBSD 5.1.2 distribution tree, and are as follows:

base The NetBSD 5.1.2 sandpoint **base** binary distribution. You *must* install this distribution set. It contains the base NetBSD utilities that are necessary for the system to run and be minimally functional.

comp Things needed for compiling programs. This set includes the system include files (`/usr/include`) and the various system libraries (except the shared libraries, which are included as part of the **base** set). This set also includes the manual pages for all of the utilities it contains, as well as the system call and library manual pages.

etc This distribution set contains the system configuration files that reside in `/etc` and in several other places. This set *must* be installed if you are installing the system from scratch, but should *not* be used if you are upgrading.

games This set includes the games and their manual pages.

kern-GENERIC
This set contains a NetBSD/sandpoint 5.1.2 `GENERIC` kernel, named `/netbsd`. You *must* install this distribution set.

man This set includes all of the manual pages for the binaries and other software contained in the **base** set. Note that it does not include any of the manual pages that are included in the other sets.

misc This set includes the system dictionaries, the typesettable document set, and other files from `/usr/share`.

text This set includes NetBSD's text processing tools, including `groff`(1), all related programs, and their manual pages.

NetBSD maintains its own set of sources for the X Window System in order to assure tight integration and compatibility. These sources are based on XFree86 4.5.0. Binary sets for the X Window System are distributed with NetBSD. The sets are:

xbase The basic files needed for a complete X client environment. This does not include the X servers.

xcomp The extra libraries and include files needed to compile X source code.

xfont Fonts needed by the X server and by X clients.

xetc Configuration files for X which could be locally modified.

xserver The X server.

The sandpoint binary distribution sets are distributed as gzipped tar files named with the extension **.tgz**, e.g. `base.tgz`.

The instructions given for extracting the source sets work equally well for the binary sets, but it is worth noting that if you use that method, the filenames stored in the sets are relative and therefore the files are extracted *below the current directory*. Therefore, if you want to extract the binaries into your system, i.e. replace the system binaries with them, you have to run the **`tar -xzpf`** command from the root directory (`/`) of your system.

Note: Each directory in the sandpoint binary distribution also has its own checksum files, just as the source distribution does.

NetBSD/sandpoint System Requirements and Supported Devices

Currently, NetBSD/sandpoint requires the use of Motorola's DINK32 ROM to load over a serial port. This means that there is no way to boot from a local disk or PCI device.

Supported processor cards

- Unity X4 with MPC8240
- Altimus X3 with either MPC755 or MPC7410

Other PMCs should work, but may need minor adjustments or more substantial work to support additional functionality.

Supported devices

- Ethernet
  - Asante Mac 10/100 PCI Rev A, part number 09-00169-01 (*de*)
  - Farallon Fast EtherTX 10/100, part number PN996L-TX (*de*)

- SMC Etherpower II (9432TX) (*epic*)
- SMC 83c170 (*epic*)
- 3Com 3c905 (*ex*)
- Intel EtherExpress PRO/10+ PCI LAN Adapter (*fxp*)
- Realtek 8029 Ethernet (*ne*)
- VIA Technologies VT86C926 (*ne*)
- D-Link DFE-530TX+ (*rtk*)
- Realtek 8139 (*rtk*)
- Netgear FA-311 (*sip*)
- Lite-On PNIC (*tlp*)
- D-Link DFE-530TX (*vr*)
- Many other PCI Ethernet interfaces, such as Tulip-compatible (*de* and *tlp*), 3Com (*ep*), SMC (*epic*), Intel (*fxp*), NE2000-compatible (*ne*), and Realtek (*rtk*)

• SCSI
- Adaptec PCI controllers 291x, 2920, 2930C, 294x, 295x, 39xx, 19160, 29160 and AIC-78xx (*ahc*)
- AdvanSys ABP-940UW[68], ABP-970UW[68], ASB3940UW-00 SCSI host adapters (*adw*)
- AdvanSys 1200[A,B], 9xx[U,UA] SCSI controller (*adv*)
- AMD 53c974 (*pcscp*)
- DPT SmartCache/SmartRAID (*dpt*)
- NCR/Symbios 53C8xx (*siop* or *esiop*)
- Many other PCI SCSI controllers should work, but no one has tried them
- Most SCSI disk/tape/CD-ROM devices should work

• IDE
- Promise Ultra66 (*pciide*)
- Some other PCI IDE controllers should work, although no one has had much success
- Most IDE disk/CD-ROM/ATAPI devices should work

• Audio
- PCI audio cards, although none have been tested.

• Serial ports
- On-board serial ports (the modem and printer ports) (*com0* and *com1*)
- Some PCI serial ports should work, but no one has tried them

• PCI cards
- Most MI PCI cards should work, although very few have been tested with NetBSD/sandpoint

  http://www.NetBSD.org/support/hardware/pci.html

Unsupported devices

- Built-in PS/2 keyboard & mouse
- Built-in parallel
- Built-in floppy
- Built-in IDE

Supported boot devices and media

Currently, the only way to boot the system is with the DINK32 ROM monitor's serial download or a JTAG device.

Getting the NetBSD System on to Useful Media

Note that if you are installing or upgrading from writable media, it can be write-protected if you wish. These systems mount a root image from inside the kernel, and will not need to write to the media. If you booted from a floppy, the floppy disk may be removed from the drive after the system has booted.

Installation is supported from several media types, including:

- CD-ROM / DVD
- MS-DOS floppy
- FTP
- Remote NFS partition
- Tape
- Existing NetBSD partitions, if performing an upgrade

The steps necessary to prepare the distribution sets for installation depend upon which installation medium you choose. The steps for the various media are outlined below.

CD-ROM / DVD Find out where the distribution set files are on the CD-ROM or DVD. Likely locations are `binary/sets` and `sandpoint/binary/sets`.

Proceed to the instructions on installation.

MS-DOS floppy NetBSD does not include split distribution sets for installation by floppy. However, they can be created on a separate machine using the `split`(1) command, running e.g. **`split -b 235k base.tgz base.`** to split the `base.tgz` file from `sandpoint/binary/sets` into files named `base.aa`, `base.ab`, and so on. Repeat this for all `set_name.tgz` files, splitting them into `set_name.`*xx* files. Count the number of `set_name.`*xx* files that make up the distribution sets you want to install or upgrade. You will need one sixth that number of 1.44 MB floppies.

Format all of the floppies with MS-DOS. Do *not* make any of them bootable MS-DOS floppies, i.e. don't use `format /s` to format them. (If the floppies are bootable, then the MS-DOS system files that make them bootable will take up some space, and you won't be able to fit the distribution set parts on the disks.) If you're using floppies that are formatted for MS-DOS by their manufacturers, they probably aren't bootable, and you can use them out of the box.

Place all of the `set_name.`*xx* files on the MS-DOS disks.

Once you have the files on MS-DOS disks, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

FTP The preparations for this installation/upgrade method are easy; all you need to do is make sure that there's an FTP site from which you can retrieve the NetBSD distribution when you're about to install or upgrade. If you don't have DHCP available on your network, you will need to know the numeric IP address of that site, and, if it's not on a network directly connected to the machine on which you're installing or upgrading NetBSD, you need to know the numeric IP address of the router closest to the NetBSD machine. Finally, you need to know the numeric IP address of the NetBSD machine itself.

Once you have this information, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

NFS Place the NetBSD distribution sets you wish to install into a directory on an NFS server, and make that directory mountable by the machine on which you are installing or upgrading NetBSD. This will probably require modifying the `/etc/exports` file on the NFS server and resetting its mount daemon (mountd). (Both of these actions will probably require superuser privileges on the server.)

You need to know the numeric IP address of the NFS server, and, if you don't have DHCP available on your network and the server is not on a network directly connected to the machine on which you're installing or upgrading NetBSD, you need to know the numeric IP address of the router closest to the NetBSD machine. Finally, you need to know the numeric IP address of the NetBSD machine itself.

Once the NFS server is set up properly and you have the information mentioned above, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

Tape To install NetBSD from a tape, you need to make a tape that contains the distribution set files, in 'tar' format.

If you're making the tape on a UNIX-like system, the easiest way to do so is probably something like:

```
# tar -cf tape_device dist_directories
```

where *tape_device* is the name of the tape device that describes the tape drive you're using; possibly `/dev/rst0`, or something similar, but it will vary from system to system. (If you can't figure it out, ask your system administrator.) In the above example, *dist_directories* are the distribution sets' directories, for the distribution sets you wish to place on the tape. For instance, to put the **kern-GENERIC, base,** and **etc** distributions on tape (in order to do the absolute minimum installation to a new disk), you would do the following:

```
# cd .../NetBSD-5.1.2
# cd sandpoint/binary
# tar -cf tape_device kern-GENERIC base etc
```

Note: You still need to fill in *tape_device* in the example.

Once you have the files on the tape, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

Preparing your System for NetBSD installation

When installing NetBSD for your NetBSD 5.1.2 system, you have to decide where you want your root partition and how you'll be downloading your kernel. Since the IBM ROM rather limits your boot options, you won't be able to have the machine boot independently. Once you load the kernel, however, you may have the root file system on a local disk or you can configure a diskless setup.

In either case, you'll need to set up to boot the kernel over the network or over a serial line.

Booting over a serial line

This is not currently documented or supported. If you would like to attempt this and supply documentation, please do!

Installing the NetBSD System

Booting the installer

Once the kernel is downloaded, type "go 90000" to start the kernel.

Example of a normal boot

Of course, a lot of the information in this example depends on your model and what your boot method is, but we'll include this anyways just so you get an idea of what to expect (user-typed commands are in **bold**).

```
DINK32>> go 90000
[ XXX - insert boot w/ installer on ramdisk instead of this example ]
```

Common Problems and Error Messages

Insufficient data.

Running the sysinst installation program

1. *Introduction*

   Using **sysinst**, installing NetBSD is a relatively easy process. Still, you should read this document and have it in hand when doing the installation process. This document tries to be a good guide to the installation, and as such, covers many details for the sake of completeness. Do not let this discourage you; the install program is not hard to use.

2. *Possible hardware problems*

   Should you encounter hardware problems during installation, try rebooting after unplugging removable devices you don't need for installation. Non-removable devices can be disabled with **userconf** (use **boot -c** to enter it).

3. *General*

   The following is a walk-through of the steps you will take while getting NetBSD installed on your hard disk. **sysinst** is a menu driven installation system that allows for some freedom in doing the installation. Sometimes, questions will be asked and in many cases the default answer will be displayed in brackets ("[ ]") after the question. If you wish to stop the installation, you may press `CONTROL-C` at any time, but if you do, you'll have to begin the installation process again from scratch by running the `/sysinst` program from the command prompt. It is not necessary to reboot.

4. *Quick install*

   First, let's describe a quick install. The other sections of this document go into the installation procedure in more detail, but you may find that you do not need this. If you want detailed instructions, skip to the next section. This section describes a basic installation, using a CD-ROM install as an example.

   - What you need.
     - The distribution sets (in this example, they are on CD).
     - One 1.44 MB 3.5" floppy.
     - A CD-ROM drive (SCSI), a hard disk and a minimum of of memory installed.

- The hard disk should have at least + *n* megabytes of space free, where *n* is the number of megabytes of main memory in your system. If you wish to install the X Window System as well, you will need at least 215 MB more.

• The Quick Installation

- Insert the first boot floppy you just created and boot the computer. After language selection, the main menu will be displayed.

```
.***********************************************.
* NetBSD-5.1.2 Install System                  *
*                                               *
*>a: Install NetBSD to hard disk                *
* b: Upgrade NetBSD on a hard disk              *
* c: Re-install sets or install additional sets *
* d: Reboot the computer                        *
* e: Utility menu                               *
* x: Exit Install System                        *
.***********************************************.
```

- If you wish, you can configure some network settings immediately by choosing the **Utility menu** and then **Configure network**. It isn't actually required at this point, but it may be more convenient. Go back to the main menu.
- Choose **install**.
- You will be guided through some steps regarding the setup of your disk, and the selection of distributed components to install. When in doubt, refer to the rest of this document for details.
- After your disk has been prepared, choose **CD-ROM** as the medium. The default values for the path and device should be ok.
- After all the files have been unpacked, go back to the main menu and select **reboot**, after you have removed the bootfloppy from the drive.
- NetBSD will now boot. If you haven't already done so in **sysinst**, you should log in as `root` and set a password for that account. You are also advised to edit `/etc/rc.conf` to match your needs.
- Your installation is now complete.

5. *Booting NetBSD*

Boot your machine. The boot loader will start, and will print a countdown and begin booting.

If the boot loader messages do not appear in a reasonable amount of time, you either have a bad boot floppy or a hardware problem. Try writing the install floppy image to a different disk, and using that.

It will take a while to load the kernel from the floppy, probably around a minute or so, then, the kernel boot messages will be displayed. This may take a little while also, as NetBSD will be probing your system to discover which hardware devices are installed. The most important thing to know is that `wd0` is NetBSD's name for your first IDE disk, `wd1` the second, etc. `sd0` is your first SCSI disk, `sd1` the second, etc.

Note that once the system has finished booting, you need not leave the floppy in the disk drive.

Once NetBSD has booted and printed all the boot messages, you will be presented with a welcome message and a main menu. It will also include instructions for using the menus.

6. *Network configuration*

   If you do not intend to use networking during the installation, but you do want your machine to be configured for networking once it is installed, you should first go to the **Utility menu** and select the **Configure network** option. If you only want to temporarily use networking during the installation, you can specify these parameters later. If you are not using the Domain Name System (DNS), you can give an empty response when asked to provide a server.

7. *Installation drive selection and parameters*

   To start the installation, select **Install NetBSD to hard disk** from the main menu.

   The first thing is to identify the disk on which you want to install NetBSD. **sysinst** will report a list of disks it finds and ask you for your selection. You should see disk names like `sd0` or `sd1`.

8. *Selecting which sets to install*

   The next step is to choose which distribution sets you wish to install. Options are provided for full, minimal, and custom installations. If you choose sets on your own, **base**, **etc**, and a kernel must be selected.

9. *Partitioning the disk*

   - Which portion of the disk to use.

     You will be asked if you want to use the entire disk or only part of the disk. If you decide to use the entire disk for NetBSD, **sysinst** will check for the presence of other operating systems and you will be asked to confirm that you want to overwrite these.

10. *Editing the NetBSD disklabel*

    The partition table of the NetBSD part of a disk is called a *disklabel*. If your disk already has a disklabel written to it, you can choose **Use existing partition sizes**. Otherwise, select **Set sizes of NetBSD partitions**.

    After you have chosen your partitions and their sizes (or if you opted to use the existing partitions), you will be presented with the layout of the NetBSD disklabel and given one more chance to change it. For each partition, you can set the type, offset and size, block and fragment size, and the mount point. The type that NetBSD uses for normal file storage is called **4.2BSD**. A swap partition has a special type called **swap**. Some partitions in the disklabel have a fixed purpose.

    `a` Root partition (/)

    `b` Swap partition.

    `c` The NetBSD portion of the disk.

    `d-p` Available for other use. Traditionally, `e` is the partition mounted on `/usr`, but this is historical practice and not a fixed value.

    You will then be asked to name your disk's disklabel. The default response will be ok for most purposes. If you choose to name it something different, make sure the name is a single word and contains no special characters. You don't need to remember this name.

11. *Preparing your hard disk*

    You are now at the point of no return. Nothing has been written to your disk yet, but if you confirm that you want to install NetBSD, your hard drive will be modified. If you are sure you want to proceed, select **yes**.

The install program will now label your disk and make the file systems you specified. The file systems will be initialized to contain NetBSD bootstrapping binaries and configuration files. You will see messages on your screen from the various NetBSD disk preparation tools that are running. There should be no errors in this section of the installation. If there are, restart from the beginning of the installation process. Otherwise, you can continue the installation program after pressing the return key.

12. *Getting the distribution sets*

    The NetBSD distribution consists of a number of *sets* that come in the form of gzipped tarfiles. At this point, you will be presented with a menu which enables you to choose from one of the following methods of installing the sets. Some of these methods will first load the sets on your hard disk, others will extract the sets directly.

    For all these methods, the first step is making the sets available for extraction, and then do the actual installation. The sets can be made available in a few different ways. The following sections describe each of those methods. After reading the one about the method you will be using, you can continue to the section labeled 'Extracting the distribution sets'.

13. *Installation from CD-ROM*

    When installing from a CD-ROM, you will be asked to specify the device name for your CD-ROM drive (usually `cd0`), and the directory name on the CD-ROM where the distribution files are.

    sysinst will then check if the files are indeed available in the specified location, and proceed to the actual extraction of the sets.

14. *Installation using ftp*

    To be able to install using ftp, you first need to configure your network setup if you haven't already done so. **sysinst** will do this for you, asking you if you want to use DHCP. If you do not use DHCP, you can enter network configuration details yourself. If you do not have DNS set up for the machine that you are installing on, you can just press RETURN in answer to this question, and DNS will not be used.

    You will also be asked to specify the host that you want to transfer the sets from, the directory on that host, the account name and password used to log into that host using ftp, and optionally a proxy server to use. If you did not set up DNS, you will need to specify an IP address instead of a hostname for the ftp server.

    sysinst will proceed to transfer all the default set files from the remote site to your hard disk.

15. *Installation using NFS*

    To be able to install using NFS, you first need to configure your network setup if you haven't already done so. **sysinst** will do this for you, asking you if you want to use DHCP. If you do not use DHCP, you can enter network configuration details yourself. If you do not have DNS set up for the machine that you are installing on, you can just press RETURN in answer to this question, and DNS will not be used.

    You will also be asked to specify the host that you want to transfer the sets from and the directory on that host that the files are in. This directory should be mountable by the machine you are installing on, i.e., correctly exported to your machine.

    If you did not set up DNS, you will need to specify an IP address instead of a hostname for the NFS server.

16. *Installation from an unmounted file system*

    In order to install from a local file system, you will need to specify the device that the file system resides on (for example `sd1e`) the type of the file system, and the directory on the specified file system where the sets are located. **sysinst** will then check if it can indeed access the sets at that location.

17. *Installation from a local directory*

    This option assumes that you have already done some preparation yourself. The sets should be located in a directory on a file system that is already accessible. **sysinst** will ask you for the name of this directory.

18. *Extracting the distribution sets*

    Before extraction begins, you can elect to watch the files being extracted; the name of each file that is extracted will be shown. This can slow down the installation process considerably on machines with slow graphics consoles or serial consoles. Alternatively, you can choose to see a progress bar. This is the preferred option as it shows progress without significantly slowing down the installation process.

    After all the files have been extracted, the device node files will be created. If you have already configured networking, you will be asked if you want to use this configuration for normal operation. If so, these values will be installed in the network configuration files. The next menu will allow you to select the time zone that you're in, to make sure your clock has the right offset from UTC. Finally you will be asked to select a password encryption algorithm and can then set a password for the "root" account, to prevent the machine from coming up without access restrictions.

19. *Finalizing your installation*

    Congratulations, you have successfully installed NetBSD 5.1.2. You can now reboot the machine and boot NetBSD from hard disk.

Post installation steps

Once you've got the operating system running, there are a few things you need to do in order to bring the system into a properly configured state. The most important steps are described below.

1. Configuring `/etc/rc.conf`

   If you or the installation software haven't done any configuration of `/etc/rc.conf` (**sysinst** usually will), the system will drop you into single user mode on first reboot with the message

   ```
   /etc/rc.conf is not configured. Multiuser boot aborted.
   ```

   and with the root file system (`/`) mounted read-only. When the system asks you to choose a shell, simply press RETURN to get to a `/bin/sh` prompt. If you are asked for a terminal type, respond with **vt220** (or whatever is appropriate for your terminal type) and press RETURN. You may need to type one of the following commands to get your delete key to work properly, depending on your keyboard:

   ```
   # stty erase '^h'
   # stty erase '^?'
   ```

   At this point, you need to configure at least one file in the `/etc` directory. You will need to mount your root file system read/write with:

   ```
   # /sbin/mount -u -w /
   ```

   Change to the `/etc` directory and take a look at the `/etc/rc.conf` file. Modify it to your tastes, making sure that you set `rc_configured=YES` so that your changes will be enabled and a multi-user boot can proceed. Default values for the various programs can be found in `/etc/defaults/rc.conf`, where some in-line documentation may be found. More complete documentation can be found in `rc.conf`(5).

   When you have finished editing `/etc/rc.conf`, type **exit** at the prompt to leave the single-user shell and continue with the multi-user boot.

   Other values that may need to be set in `/etc/rc.conf` for a networked environment are *hostname* and possibly *defaultroute*. You may also need to add an *ifconfig_int* for your ⟨int⟩ network interface, along the lines of

```
ifconfig_tlp0="inet 192.0.2.123 netmask 255.255.255.0"
```

or, if you have *myname.my.dom* in `/etc/hosts`:

```
ifconfig_tlp0="inet myname.my.dom netmask 255.255.255.0"
```

To enable proper hostname resolution, you will also want to add an `/etc/resolv.conf` file or (if you are feeling a little more adventurous) run `named`(8). See `resolv.conf`(5) or `named`(8) for more information. Instead of manually configuring network and naming service, DHCP can be used by setting `dhclient=YES` in `/etc/rc.conf`.

Other files in `/etc` that may require modification or setting up include `/etc/mailer.conf`, `/etc/nsswitch.conf`, and `/etc/wscons.conf`.

2. Logging in

   After reboot, you can log in as `root` at the login prompt. Unless you've set a password in **sysinst**, there is no initial password. You should create an account for yourself (see below) and protect it and the "root" account with good passwords. By default, root login from the network is disabled (even via `ssh`(1)). One way to become root over the network is to log in as a different user that belongs to group "wheel" (see `group`(5)) and use `su`(1) to become root.

3. Adding accounts

   Use the `useradd`(8) command to add accounts to your system. Do not edit `/etc/passwd` directly! See `vipw`(8) and `pwd_mkdb`(8) if you want to edit the password database.

4. The X Window System

   If you installed the X Window System, you may want to read the chapter about X in the NetBSD Guide:
   http://netbsd.org/docs/guide/en/chap-x.html

5. Installing third party packages

   If you wish to install any of the software freely available for UNIX-like systems you are strongly advised to first check the NetBSD package system, pkgsrc. pkgsrc automatically handles any changes necessary to make the software run on NetBSD. This includes the retrieval and installation of any other packages on which the software may depend.

   - More information on the package system is available at
     http://www.NetBSD.org/docs/software/packages.html
   - A list of available packages suitable for browsing is at
     ftp://ftp.NetBSD.org/pub/NetBSD/packages/pkgsrc/README.html
   - Precompiled binaries can be found at
     ftp://ftp.NetBSD.org/pub/pkgsrc/packages/NetBSD/
     usually in the `sandpoint/5.1.2/All` subdir. You can install them with the following commands under `sh`(1):

```
# PKG_PATH=ftp://ftp.NetBSD.org/pub/pkgsrc/packages/NetBSD/sandpoint/5.1.2/All
# export PKG_PATH
# pkg_add -v tcsh
# pkg_add -v bash
# pkg_add -v perl
# pkg_add -v apache
# pkg_add -v kde
# pkg_add -v firefox
...
```

If you are using csh(1) then replace the first two lines with the following:

```
# setenv PKG_PATH ftp://ftp.NetBSD.org/pub/pkgsrc/packages/NetBSD/sandpoint/5.1
```

Note: Some mirror sites don't mirror the /pub/pkgsrc directory. If you would like to use such mirrors, you could also try the /pub/NetBSD/packages/current-packages/NetBSD/sandpoint/5.1.2/All directory, which may have the same contents.

The above commands will install the Tenex-csh and Bourne Again shells, the Perl programming language, Apache web server, KDE desktop environment and the Firefox web browser as well as all the packages they depend on.

Note: In some cases the pkg_add(1) command will complain about a version mismatch of packages with a message like the following:

```
Warning: package 'foo' was built for a different version
of the OS:
NetBSD/i386 M.N (pkg) vs. NetBSD/i386 5.1.2 (this host),
```

This warning is harmless if the formal major release numbers are the same between the pkg and your host. Please refer to the NetBSD release glossary and graphs at

http://www.NetBSD.org/releases/release-map.html

for more information about NetBSD's release numbering scheme.

- The framework for compiling packages can be obtained by retrieving the file

  ftp://ftp.NetBSD.org/pub/NetBSD/packages/pkgsrc.tar.gz

  It is typically extracted into /usr/pkgsrc (though other locations work fine) with the commands:

  ```
  # cd /usr
  # tar -zxpf pkgsrc.tar.gz
  ```

  After extracting, see the doc/pkgsrc.txt file in the extraction directory (e.g., /usr/pkgsrc/doc/pkgsrc.txt) for more information.

6. Misc

- Edit /etc/mail/aliases to forward root mail to the right place. Don't forget to run newaliases(1) afterwards.
- The /etc/postfix/main.cf file will almost definitely need to be adjusted. If you prefer a different MTA, then install it using pkgsrc or by hand and adjust /etc/mailer.conf.
- Edit /etc/rc.local to run any local daemons you use.
- Many of the /etc files are documented in section 5 of the manual; so just invoking

  ```
  # man 5 filename
  ```

  is likely to give you more information on these files.

Upgrading a previously-installed NetBSD System

The easiest way to upgrade to NetBSD 5.1.2 is with binaries, and that is the method documented here.

To do the upgrade, you must have one form of boot media available. You must also have at least the **base** and **kern** binary distribution sets available. Finally, you must have sufficient disk space available to install the new binaries. Since files already installed on the system are overwritten in place, you only need additional free space for files which weren't previously installed or to account for growth of the sets between releases. If you have a few megabytes free on each of your root (/) and /usr partitions, you should have enough space.

Since upgrading involves replacing the kernel, boot blocks, and most of the system binaries, it has the potential to cause data loss. You are strongly advised to *back up* any important data on the NetBSD partition or on another operating system's partition on your disk before beginning the upgrade process.

The upgrade procedure is similar to an installation, but without the hard disk partitioning. **sysinst** will attempt to merge the settings stored in your /etc directory with the new version of NetBSD. Also, file systems are checked before unpacking the sets. Fetching the binary sets is done in the same manner as the installation procedure; refer to the installation part of the document for help.

After a new kernel has been copied to your hard disk, your machine is a complete NetBSD 5.1.2 system. However, that doesn't mean that you're finished with the upgrade process. You will probably want to update the set of device nodes you have in /dev. If you've changed the contents of /dev by hand, you will need to be careful about this, but if not, you can just cd into /dev, and run the command:

```
# sh MAKEDEV all
```

Finally, you will want to delete old binaries that were part of the version of NetBSD that you upgraded from and have since been removed from the NetBSD distribution.

Compatibility Issues With Previous NetBSD Releases

Users upgrading from previous versions of NetBSD may wish to bear the following problems and compatibility issues in mind when upgrading to NetBSD 5.1.2.

Note: None of the items mentioned below are relevant if upgrading from 5.1. They still apply if you are upgrading from a pre-5.1 release, though.

If your port uses X.Org and you see messages from the X server indicating that no devices were found, you may need to run **X -configure** and update your existing xorg.conf to use the BusID line from the newly-generated config file.

Dual-head support for PC systems has become broken for many configurations with the update to xorg-server 1.6.x, which has removed the userland PCI configuration mechanism, and needs to rely upon the OS. We hope to correct this for future releases. Workaround: The only workaround is non-trivial and requires programming several PCI BAR registers as they previously were in NetBSD 5.0.

If you are updating to NetBSD 5.1.2 without the aid of sysinst or postinstall and your port uses X.Org, be sure to remove /usr/X11R7/lib/X11/xkb/symbols/pc before extracting the xbase set. In the version of X.Org shipped with 5.0, this was a directory, but in more recent X.Org versions it is a file.

pkg_install now depends on the pkgdb cache for automatic conflict detection. It is recommended to rebuild the cache with

```
# pkg_admin rebuild
```

audit-packages.conf(5) has been superseded by pkg_install.conf(5). The default configuration is the same.

Support for pkg_view(1) has been retired.

The functionality of audit-packages(1) and download-vulnerability-list(1) has moved into pkg_admin(1). However, wrapper scripts that handle the common use cases are provided.

Issues when running older binaries on NetBSD 5.1.2

The pthread libraries from previous versions of NetBSD require that the sysctl(3) node kern.no_sa_support be set to 0. This affects the following environments:

- Running a 5.x kernel with an older userland.

- Running an older userland inside a chroot'ed environment on a 5.x system.
- Running older statically linked pthread applications.

The 5.x kernel defaults to `0` for `kern.no_sa_support`, which covers the first case. However, please note that a full installation of 5.x (either from scratch or through an upgrade) will set `kern.no_sa_support` to 1 during the boot process. This means that for the last two cases, you will have to manually set `kern.no_sa_support` to `0`, using either the `sysctl`(8) command or through `sysctl.conf`(5).

Note that **`sysinst`** will automatically invoke

```
postinstall fix
```

and thus all issues that are fixed by **`postinstall`** by default (see below) will be handled.

Issues affecting an upgrade from NetBSD 3.x releases

See the section below on upgrading from NetBSD 4.x as well.

The following issues can generally be resolved by running *postinstall* with the **etc** set:

```
postinstall -s /path/to/etc.tgz check
postinstall -s /path/to/etc.tgz fix
```

Issues fixed by *postinstall*:

- Various files in `/etc` need upgrading. These include:
  - `/etc/defaults/*`
  - `/etc/mtree/*`
  - `/etc/daily`
  - `/etc/weekly`
  - `/etc/monthly`
  - `/etc/security`
  - `/etc/rc.subr`
  - `/etc/rc`
  - `/etc/rc.shutdown`
  - `/etc/rc.d/*`
  - `/etc/envsys.conf`

The following issues need to be resolved manually:

- The users '_proxy', '_rwhod', and '_sdpd' and the groups '_proxy', '_rwhod' and '_sdpd' need to be created and the user 'uucp' needs to be updated.
- A number of things were removed in the NetBSD 4.0 release, including: the evbsh5 port, the Fortran 77 compiler (g77), NETCCITT, NETNS, Sendmail, Sushi, UUCP, and Vinum. If you were using any of these, please see the "Components removed from NetBSD" at

  http://www.NetBSD.org/releases/formal-4/NetBSD-4.0.html#removals
- The replacement of Sendmail by Postfix can be handled automatically by *postinstall* but it is not done by default. If you want to transition to Postfix, the command

  ```
  postinstall -s /path/to/etc.tgz fix mailerconf
  ```

  will update your `/etc/mailer.conf` file to use Postfix as the MTA. When using **`sysinst`** to upgrade the system, it will ask if you want this to be done.

  Note that if you have a customized Sendmail setup, you need to set up Postfix in an equivalent way; there is no tool for automatic conversion of Sendmail configuration to a Postfix one.

Postfix will be started automatically when the system boots. You may see messages like "$sendmail is not set properly" at boot. You can suppress them by removing `/etc/rc.d/sendmail` and `/etc/rc.d/smmsp`. Those files and other parts of sendmail configuration like files under `/usr/share/sendmail` are not removed by default while upgrading for those who want to continue using sendmail from outside the base system. If you want to delete them, *postinstall* can be used:

```
postinstall -s /path/to/etc.tgz fix sendmail
```

Issues affecting an upgrade from NetBSD 4.x releases

The following issues can generally be resolved by running *postinstall* with the **etc** set:

```
postinstall -s /path/to/etc.tgz check
postinstall -s /path/to/etc.tgz fix
```

Issues fixed by *postinstall*:

- Various files in `/etc` need upgrading. These include:
  - `/etc/defaults/*`
  - `/etc/mtree/*`
  - `/etc/daily`
  - `/etc/weekly`
  - `/etc/monthly`
  - `/etc/security`
  - `/etc/rc.subr`
  - `/etc/rc`
  - `/etc/rc.shutdown`
  - `/etc/rc.d/*`
  - `/etc/envsys.conf`

The following issues need to be resolved manually:

- The users '_httpd' and '_timedc' and the groups '_httpd' and '_timedc' need to be created.
- Unprivileged use of the `mount`(8) command now requires the *`nosuid`* and *`nodev`* options to be explicitly specified. Previously, these options were automatically enforced even if they were not explicitly specified.
- A number of things have been removed from the NetBSD 5.1.2 release. See the "Components removed from NetBSD" section near the beginning of this document for a list.

Using online NetBSD documentation

Documentation is available if you installed the manual distribution set. Traditionally, the "man pages" (documentation) are denoted by '`name(section)`'. Some examples of this are

- `intro`(1),
- `man`(1),
- `apropos`(1),
- `passwd`(1), and
- `passwd`(5).

The section numbers group the topics into several categories, but three are of primary interest: user commands are in section 1, file formats are in section 5, and administrative information is in section 8.

The *man* command is used to view the documentation on a topic, and is started by entering **`man`** [*`section`*] *`topic`*. The brackets [] around the section should not be entered, but rather indicate that the section is optional. If you don't ask for a particular section, the topic with the lowest numbered section name will be displayed. For instance, after logging in, enter

```
# man passwd
```

to read the documentation for `passwd`(1). To view the documentation for `passwd`(5), enter

```
# man 5 passwd
```

instead.

If you are unsure of what man page you are looking for, enter

```
# apropos subject-word
```

where *subject-word* is your topic of interest; a list of possibly related man pages will be displayed.

Administrivia

If you've got something to say, do so! We'd like your input. There are various mailing lists available via the mailing list server at `majordomo@NetBSD.org`. To get help on using the mailing list server, send mail to that address with an empty body, and it will reply with instructions. See **http://www.NetBSD.org/mailinglists/** for a web interface.

There are various mailing lists set up to deal with comments and questions about this release. Please send comments to: `netbsd-comments@NetBSD.org`.

To report bugs, use the `send-pr`(1) command shipped with NetBSD, and fill in as much information about the problem as you can. Good bug reports include lots of details.

Bugs also can be submitted and queried with the web interface at
http://www.NetBSD.org/support/send-pr.html

There are also port-specific mailing lists, to discuss aspects of each port of NetBSD. Use majordomo to find their addresses, or visit **http://www.NetBSD.org/mailinglists/**

If you're interested in doing a serious amount of work on a specific port, you probably should contact the 'owner' of that port (listed below).

If you'd like to help with this effort, and have an idea as to how you could be useful, send us mail or subscribe to: `netbsd-users@NetBSD.org`.

As a favor, please avoid mailing huge documents or files to these mailing lists. Instead, put the material you would have sent up for FTP or WWW somewhere, then mail the appropriate list about it, or, if you'd rather not do that, mail the list saying you'll send the data to those who want it.

Thanks go to

- The former members of UCB's Computer Systems Research Group, including (but not limited to):

  Keith Bostic
  Ralph Campbell
  Mike Karels
  Marshall Kirk McKusick

  for their work on BSD systems, support, and encouragement.
- The Internet Systems Consortium, Inc. for hosting the NetBSD FTP, CVS, AnonCVS, mail, mail archive, GNATS, SUP, Rsync and WWW servers.
- The Internet Research Institute in Japan for hosting the server which runs the CVSweb interface to the NetBSD source tree.

- The Luleå Academic Computer Society for providing the backup services server.
- The Columbia University Computer Science Department for hosting the NYC build cluster.
- The Western Washington University Computer Science Department for running the WWU build cluster.
- The many organizations that provide NetBSD mirror sites.
- Without CVS, this project would be impossible to manage, so our hats go off to Brian Berliner, Jeff Polk, and the various other people who've had a hand in making CVS a useful tool.
- We list the individuals and organizations that have made donations or loans of hardware and/or money, to support NetBSD development, and deserve credit for it at **http://www.NetBSD.org/donations/** (If you're not on that list and should be, tell us! We probably were not able to get in touch with you, to verify that you wanted to be listed.)
- Finally, we thank all of the people who've put sweat and tears into developing NetBSD since its inception in January, 1993. (Obviously, there are a lot more people who deserve thanks here. If you're one of them, and would like to be mentioned, tell us!)

We are...

(in alphabetical order)

The NetBSD core group:

Alan Barrett	`apb@NetBSD.org`
Alistair Crooks	`agc@NetBSD.org`
Matthew Green	`mrg@NetBSD.org`
Chuck Silvers	`chs@NetBSD.org`
Matt Thomas	`matt@NetBSD.org`
YAMAMOTO Takashi	`yamt@NetBSD.org`
Christos Zoulas	`christos@NetBSD.org`

The portmasters (and their ports):

Erik Berls	`cyber@NetBSD.org`	**cobalt**
Manuel Bouyer	`bouyer@NetBSD.org`	**xen**
Simon Burge	`simonb@NetBSD.org`	**evbmips**
Simon Burge	`simonb@NetBSD.org`	**pmax**
Simon Burge	`simonb@NetBSD.org`	**sbmips**
Julian Coleman	`jdc@NetBSD.org`	**atari**
Andrew Doran	`ad@NetBSD.org`	**amd64**
Andrew Doran	`ad@NetBSD.org`	**i386**
Matthias Drochner	`drochner@NetBSD.org`	**cesfic**
Gavan Fantom	`gavan@NetBSD.org`	**iyonix**
Nick Hudson	`skrll@NetBSD.org`	**hp700**
Martin Husemann	`martin@NetBSD.org`	**sparc64**
Søren Jørvang	`soren@NetBSD.org`	**sgimips**
Takayoshi Kochi	`kochi@NetBSD.org`	**ia64**
Michael Lorenz	`macallan@NetBSD.org`	**macppc**
Anders Magnusson	`ragge@NetBSD.org`	**vax**
Tohru Nishimura	`nisimura@NetBSD.org`	**luna68k**
Tohru Nishimura	`nisimura@NetBSD.org`	**sandpoint**

Scott Reynolds	`scottr@NetBSD.org`	**mac68k**
Tim Rightnour	`garbled@NetBSD.org`	**ofppc**
Tim Rightnour	`garbled@NetBSD.org`	**prep**
Tim Rightnour	`garbled@NetBSD.org`	**rs6000**
Noriyuki Soda	`soda@NetBSD.org`	**arc**
Ignatios Souvatzis	`is@NetBSD.org`	**amiga**
Ignatios Souvatzis	`is@NetBSD.org`	**amigappc**
NISHIMURA Takeshi	`nsmrtks@NetBSD.org`	**x68k**
Matt Thomas	`matt@NetBSD.org`	**alpha**
Matt Thomas	`matt@NetBSD.org`	**ibmnws**
Matt Thomas	`matt@NetBSD.org`	**netwinder**
Izumi Tsutsui	`tsutsui@NetBSD.org`	**ews4800mips**
Izumi Tsutsui	`tsutsui@NetBSD.org`	**hp300**
Izumi Tsutsui	`tsutsui@NetBSD.org`	**news68k**
Valeriy E. Ushakov	`uwe@NetBSD.org`	**hpcsh**
Valeriy E. Ushakov	`uwe@NetBSD.org`	**landisk**
Steve Woodford	`scw@NetBSD.org`	**evbppc**
Steve Woodford	`scw@NetBSD.org`	**mvme68k**
Steve Woodford	`scw@NetBSD.org`	**mvmeppc**
Reinoud Zandijk	`reinoud@NetBSD.org`	**acorn32**

The NetBSD 5.1.2 Release Engineering team:

Stephen Borrill	`sborrill@NetBSD.org`
Manuel Bouyer	`bouyer@NetBSD.org`
David Brownlee	`abs@NetBSD.org`
James Chacon	`jmc@NetBSD.org`
Julian Coleman	`jdc@NetBSD.org`
Håvard Eidnes	`he@NetBSD.org`
Alistair Grooks	`agc@NetBSD.org`
John Heasley	`heas@NetBSD.org`
Martin Husemann	`martin@NetBSD.org`
Soren Jacobsen	`snj@NetBSD.org`
Mark Kirby	`mkirby@NetBSD.org`
Phil Nelson	`phil@NetBSD.org`
Jeremy C. Reed	`reed@NetBSD.org`
Jeff Rizzo	`riz@NetBSD.org`
SAITOH Masanobu	`msaitoh@NetBSD.org`

NetBSD Developers:

Nathan Ahlstrom	`nra@NetBSD.org`
Steve Allen	`wormey@NetBSD.org`
Jukka Andberg	`jandberg@NetBSD.org`
Julian Assange	`proff@NetBSD.org`
Lennart Augustsson	`augustss@NetBSD.org`
Christoph Badura	`bad@NetBSD.org`
Bang Jun-Young	`junyoung@NetBSD.org`
Dieter Baron	`dillo@NetBSD.org`
Robert V. Baron	`rvb@NetBSD.org`

Alan Barrett	apb@NetBSD.org
Grant Beattie	grant@NetBSD.org
Jason Beegan	jtb@NetBSD.org
Erik Berls	cyber@NetBSD.org
Hiroyuki Bessho	bsh@NetBSD.org
John Birrell	jb@NetBSD.org
Mason Loring Bliss	mason@NetBSD.org
Charles Blundell	cb@NetBSD.org
Rafal Boni	rafal@NetBSD.org
Stephen Borrill	sborrill@NetBSD.org
Sean Boudreau	seanb@NetBSD.org
Manuel Bouyer	bouyer@NetBSD.org
John Brezak	brezak@NetBSD.org
Allen Briggs	briggs@NetBSD.org
Mark Brinicombe	mark@NetBSD.org
Aaron Brown	abrown@NetBSD.org
Andrew Brown	atatat@NetBSD.org
David Brownlee	abs@NetBSD.org
Frederick Bruckman	fredb@NetBSD.org
Jon Buller	jonb@NetBSD.org
Simon Burge	simonb@NetBSD.org
Robert Byrnes	byrnes@NetBSD.org
Pavel Cahyna	pavel@NetBSD.org
D'Arcy J.M. Cain	darcy@NetBSD.org
Daniel Carosone	dan@NetBSD.org
Dave Carrel	carrel@NetBSD.org
James Chacon	jmc@NetBSD.org
Mihai Chelaru	kefren@NetBSD.org
Bill Coldwell	billc@NetBSD.org
Julian Coleman	jdc@NetBSD.org
Ben Collver	ben@NetBSD.org
Marcus Comstedt	marcus@NetBSD.org
Jeremy Cooper	jeremy@NetBSD.org
Chuck Cranor	chuck@NetBSD.org
Alistair Crooks	agc@NetBSD.org
Aidan Cully	aidan@NetBSD.org
Garrett D'Amore	gdamore@NetBSD.org
Johan Danielsson	joda@NetBSD.org
John Darrow	jdarrow@NetBSD.org
Jed Davis	jld@NetBSD.org
Matt DeBergalis	deberg@NetBSD.org
Arnaud Degroote	degroote@NetBSD.org
Rob Deker	deker@NetBSD.org
Chris G. Demetriou	cgd@NetBSD.org
Tracy Di Marco White	gendalia@NetBSD.org
Jaromír Dolecek	jdolecek@NetBSD.org
Andy Doran	ad@NetBSD.org
Roland Dowdeswell	elric@NetBSD.org
Emmanuel Dreyfus	manu@NetBSD.org