NAME

INSTALL — Installation procedure for NetBSD/evbarm.

CONTENTS

About this Document....2
What is NetBSD?....2
Changes Between The NetBSD 5.0 and 6.0 Releases....3
  General kernel....3
  Networking....4
  File systems....4
  Security....4
  Drivers....4
  Platforms....7
  Userland....13
  Components removed from NetBSD....15
Features to be removed in a later release....16
The NetBSD Foundation....16
Sources of NetBSD....16
NetBSD 6.0 Release Contents....16
  NetBSD/evbarm subdirectory structure....17
  Binary distribution sets....17
NetBSD/evbarm System Requirements and Supported Devices....19
  Supported devices (Technologic Systems TS-7200)....19
    TS-5620 Real Time Clock....19
    Serial ports....19
    Ethernet adapters....19
    Other on-board functions....19
  Supported devices (ARM, Ltd. Integrator)....19
    PrimeCell PL030 Real Time Clock....19
    Serial ports....19
    SCSI host adapters....19
    Ethernet adapters....20
  Supported devices (Intel IQ80310)....20
    Serial ports....20
    Ethernet adapters....20
    i80312 Companion I/O functions....20
  Supported devices (Intel IQ80321)....20
    Serial ports....20
    Ethernet adapters....20
    i80321 I/O Processor functions....20
  Supported devices (Team ASA Npwr)....20
    Serial ports....20
    SCSI host adapters....20
    Ethernet adapters....20
  Supported devices (Intel IXM1200)....20
    Serial ports....20
    Ethernet adapters....20
  Supported devices (Samsung SMDK2800)....21
    Serial ports....21
  Supported devices (ADI BRH)....21

Serial ports....21
Ethernet adapters....21
Supported devices (Arcom Viper)....21
Serial ports....21
Ethernet adapters....21
Getting the NetBSD System on to Useful Media....21
Preparing your System for NetBSD installation....22
Preparation for the Technologic Systems TS-7200....22
Preparation for the Intel IQ80310....23
Preparation for the Intel IQ80321....25
Installing the NetBSD System....27
Installation for the Technologic Systems TS-7200....27
Installation for the Intel IQ80310....28
Installation for the Intel IQ80321....29
Post installation steps....31
Upgrading a previously-installed NetBSD System....33
Compatibility Issues With Previous NetBSD Releases....33
Issues affecting an upgrade from NetBSD 5.x releases....34
Issues affecting an upgrade from NetBSD 4.x releases....34
Using online NetBSD documentation....34
Administrivia....35
Thanks go to....35
We are....36
Legal Mumbo-Jumbo....44
The End....47

DESCRIPTION

About this Document

This document describes the installation procedure for NetBSD 6.0 on the *evbarm* platform. It is available in four different formats titled `INSTALL.`*`ext`*, where `.`*`ext`* is one of `.ps`, `.html`, `.more`, or `.txt`:

`.ps` PostScript.

`.html` Standard Internet HTML.

`.more` The enhanced text format used on UNIX-like systems by the `more`(1) and `less`(1) pager utility programs. This is the format in which the on-line *man* pages are generally presented.

`.txt` Plain old ASCII.

You are reading the *PostScript* version.

What is NetBSD?

The NetBSD Operating System is a fully functional Open Source UNIX-like operating system derived from the University of California, Berkeley Networking Release 2 (Net/2), 4.4BSD-Lite, and 4.4BSD-Lite2 sources. NetBSD runs on 57 different system architectures (ports) across 15 distinct CPU families, and is being ported to more. The NetBSD 6.0 release contains complete binary releases for many different system architectures. (A few ports are not fully supported at this time and are thus not part of the binary distribution. Please see the NetBSD web site at **http://www.NetBSD.org/** for information on them.)

NetBSD is a completely integrated system. In addition to its highly portable, high performance kernel, NetBSD features a complete set of user utilities, compilers for several languages, the X Window System, firewall software and numerous other tools, all accompanied by full source code.

NetBSD is a creation of the members of the Internet community. Without the unique cooperation and coordination the net makes possible, it's likely that NetBSD wouldn't exist.

Changes Between The NetBSD 5.0 and 6.0 Releases

The NetBSD 6.0 release provides numerous significant functional enhancements, including support for many new devices, integration of hundreds of bug fixes, new and updated kernel subsystems, and many user-land enhancements. The result of these improvements is a stable operating system fit for production use that rivals most commercially available systems.

It is impossible to completely summarize the massive development that went into the NetBSD 6.0 release. The complete list of changes can be found in the CHANGES:

http://ftp.NetBSD.org/pub/NetBSD/NetBSD-6.0/CHANGES

and CHANGES-6.0:

http://ftp.NetBSD.org/pub/NetBSD/NetBSD-6.0/CHANGES-6.0

files in the top level directory of the NetBSD 6.0 release tree.

Some highlights include:

General kernel

- `time_t` and `dev_t` are now 64 bits.
- Much-improved compat_linux support for running Linux binaries.
- Added a generic producer/consumer queue.
- Added a new ptree (Patricia / RADIX tree) implementation.
- Removed `MALLOC()` and `FREE()` macros.
- Compute `kern.ipc.shmmaxpages` on startup based on physical memory. Can be overridden via `sysctl`(8).
- `kmem_alloc`(9): Add more extensive runtime debugging facilities.
- File descriptor access performance improvements were made.
- `cpu_reboot`(9): tear down stacks of devices and file systems in an orderly fashion during shutdown.
- Added 'show vmem' and 'show all vmems' commands to `ddb`(4).
- Added high-priority `xcall`(9) support.
- Added direct select()/poll() support.
- Add PCU (Per-CPU Unit) interface to unify synchronization of per CPU context, like lazy FPU management.
- Added new system calls `pipe2`(2), `paccept`(2), `kqueue1`(2), flags SOCK_CLOEXEC/SOCK_NONBLOCK to `socket`(2), `socketpair`(2), F_DUPFD_CLOEXEC to `fcntl`(2), and a MSG_CMSG_CLOEXEC to `recvfrom`(2) to be able to set close-on-exec to all newly created file descriptors.
- Major improvements to `uvm_map`(9), `uvm_km`(9), `vmem`(9), and `kmem`(9) layers.
- Removed `ltsleep`(9) and wakeup_one(9).
- Rewrote most of the entropy-gathering and entropy-distributing code, separating the `rnd`(4) pseudodevice from the bitstream generation code `cprng`(9) and entropy-pool code `rnd`(9).

- kmem_alloc(9): add more extensive runtime debugging facilities.
- Kernel support for posix_spawn(3).

Networking

- ip(4): added IP_RECVTTL option to let recvmsg(2) return the TTL of the received datagram.
- ip(4): added IP_MINTTL option to discard packets with a TTL lower than the option value.
- Added SOCK_SEQPACKET for local sockets.
- Added net.inet.icmp.bmcastecho sysctl(7), to disable ICMP replies to the braodcast address.
- Make TCP window size autoscaling the default.
- Derive the mbuf cluster (NMBCLUSTERS) at boot time from the available memory. The default can be raised by changing kern.mbuf.nmbclusters
- Added NPF, the NetBSD Packet Filter.
- udp(4): implement RFC6056 port selection algorithms.

File systems

- Added CHFS, a file system for flash devices.
- The default behavior when mounting empty msdosfs file systems has been changed to assume long filenames. The behavior with populated file systems has not changed.
- UDF: Added support for session opening/closing on sequential media.
- ext2fs: Added support for >128 byte inodes.
- Import OpenSolaris ZFS code. Experimental-only; does not work yet.
- ffs: New quota support. This adds a new on-disk format to store disk quota usage and limits, integrated with ffs metadata. Usage is checked by fsck_ffs(8) (no more quotacheck) and is covered by the WAPBL journal. Enabled with kernel option QUOTA2.

Security

- secmodel_bsd44(9), secmodel_securelevel(9): Add provisions to control access to gpio(4) pins.
- security.conf(5): Add check_pkg_vulnerabilities and check_pkg_signatures to validate the installed packages against the vulnerabilities database and the expected checksums for their files.

Drivers

- Audio:
  - Added gcscaudio(4) driver for AMD Geode CS5536.
  - Added hdaudio(4), a new standards-compliant Intel High Definition Audio driver written to replace azalia(4).
  - audio(9): Audio drivers are now MP-safe.
- Hardware Monitoring:
  - sysmon_envsys(9): Enhancements to allow access to driver-internal limit values.

  - acpicpu(4): Add a driver for ACPI-based processor functionality.
  - acpipmtr(4): Add a driver for ACPI power meters.
  - acpismbus(4): ACPI SMBus Control Method Interface driver.
  - acpiwdrt(4): ACPI Watchdog Resource Tables driver.
  - acpiwmi(4): Windows Management Instrumentation support for ACPI. Also added mappings for wmidell(4), wmieeepc(4), wmihp(4), and wmimsi(4).
  - aibs(4): New driver for ASUSTeK AI Booster (ACPI ASOC ATK0110) hardware monitor with limit support.
  - amdtemp(4): Add support for Family 12h.
  - dbcool(4): Added support for ADM1031 thermal sensor / fan controller.

- Networking:
  - Added support for more chip revisions to re(4). Added hardware checksum support for newer PCIe 8168C/8111C/8102E chips.
  - Switch ath(4) from the binary HAL to the open-source HAL from Sam Leffler.
  - Added bwi(4) driver for Broadcom AirForce / Apple Airport Extreme network cards.
  - Added flow control and RTL8211C(L) PHY support to rgephy(4).
  - Added age(4) and atphy(4) drivers for Attansic/Atheros L1 Gigabit Ethernet and F1 PHY, respectively.
  - Added support for flow control to sk(4).
  - Added support for flow control on MCP65 to nfe(4).
  - Added TCPv4/UDPv4 RX hardware checksum support for i82559 and later chips to fxp(4).
  - wm(4): Added ICH10, PCH, PCH2, 82575, 82576, 82580 and I350 devices support. Added some other improvements and workarounds.
  - bge(4): added misc quirk code for chip specific bugs.
  - Added ale(4): Attansic/Atheros L1E Gigabit Ethernet.
  - agr(4): added support for layering vlans on top, and allow LACP to be disabled.
  - alc(4): Add a driver for Atheros AR813x/AR815x Ethernet.
  - aue(4): Add support for I-O DATA ETX-US2.
  - bnx(4): Added support for Broadcom BCM5709 and BCM5716 chips. Add support for Broadcom BCM5709S (SerDes) chip.
  - et(4), etphy(4): Add a driver for Agere/LSI ET1310/ET1301 10/100/Gigabit Ethernet device and the Agere/LSI ET1011 TruePHY Gigabit Ethernet PHY.
  - kue(4): fixed unaligned memory accesses so it now works on ARM and MIPS machines.
  - ne(4): add proper support for NE2000 8-bit mode.
  - nfe(4): Add support for flow control for MCP65.
  - otus(4): Atheros AR9100U driver.

  - smsh(4): Add a SMSC LAN9118 Family Ethernet driver.
  - upgt(4): Add a driver for Conexant/Intersil PrismGT SoftMAC USB IEEE 802.11b/g WLAN.
- Storage:
  - Added an experimental in-kernel iSCSI initiator, from Wasabi Systems.
  - viaide(4): Added VT8237S Integrated SATA controller support, and VT6410 PATA RAID controller support (without RAID).
  - Added LVM functionality with dm(4) driver and lvm2 userland tools.
  - Added support for 82965PM to piixide(4).
  - vnd(4): implemented DIOCCACHESYNC. Also, allow vnd(4) to be backed by a sparse file.
  - Added sdmmc(4) driver for SD/MMC.
  - mvsata(4): support the Marvell Hercules-I/II SATA controllers.
  - flash(9): Add a subsystem to handle flash memory devices, and nand(9), a subsystem to handle NAND controllers.
  - mfi(4): Add support for LSI's newer (GEN2) RAID controller.
  - nside(4): Add a driver for the National Semiconductor PC87415 IDE controller.
  - raid(4):
    - RAIDFrame parity maps, which greatly improve parity rewrite times after unclean shutdown.
    - Added support for non 512-byte sector devices.
    - Added support for >2TB devices.
- USB:
  - uftdi(4): Added support for REX-USB60F.
  - ehci(4): work around USB subsystem freeze for SB600/SB700 chipsets.
  - ums(4): Added touchpanel support.
- Graphics and Video:
  - drm(4): updated to mesa-drm 85b9f737db0d2a845e4d7e2bbf9ad12ff9e2227c.
  - acpivga(4): ACPI Video Extensions driver.
  - agp(4): Added support for Intel G35, Intel G45, and Intel 82855GM.
  - auvitek(4): Add a driver for Auvitek AU0828 family USB video capture controllers.
  - dtv(4): Add new digital TV framework.
  - cxdtv(4): Add driver for Conexant CX23880-based DTV cards.
  - emdtv(4): Add a driver for Empia EM28xx family USB video capture controllers.
  - omapfb(4): a simple driver for OMAP 3xxx on-chip video, especially the Beagleboard.
- Miscellaneous:
  - Added Elantech multi-touch trackpad support to pms(4).

- Added the altmem(4) "alternative memory"

  disk driver, which allows memory that is normally inaccessible by the machine-dependent pmap(9) to be used (as swap space).
- ichlpcib(4): support 82801IEM LPC Interface Bridge.
- Complete rework of gpio(4) to integrate with kauth(9), allow for runtime driver attachment, and naming of individual pins. Add gpiosim(4) driver to simulate a gpio(4) device for testing purposes.
- Added gpioiic(4) driver to bit-bang an I2C bus using GPIO pins.
- btmagic(4): Apple Magic Mouse driver.
- vmt(4): Add a VMware Tools driver, from OpenBSD.

Platforms

- x86 (i386, amd64):
  - pxeboot(8) now parses boot.cfg(5).
  - The bootloader has been enhanced to support framebuffer consoles using VESA BIOS extensions. x86 ports now work with the genfb(4) framebuffer, and the i386-only vesafb(4) framebuffer has been obsoleted.
  - Added ucas(9) support for x86.
  - sysinst(8) now defaults to UFS2 for x86 platforms.
  - CPU topology detection suport for AMD processors.
  - Enable Ext2fs support in bootloader.
  - Booting from a disk with a GUID Partition Table (GPT) is now possible.
  - Support userconf(4) command in boot.cfg(5).
- i386:
  - Use "i486"

    as GNU_ARCH.
  - Added PAE (Physical Address Extension) support.
  - Better support for VIA C7 CPUs.
- amd64:
  - Added direct map support (mapping of all physical memory using large pages).
- alpha:
  - X11: add support for X11FLAVOUR=xorg.
  - Support for Avalon A12 removed.
  - Converted Alpha to use PCU to manage FPU.
- amiga:

  - Added basic PCI support.
  - `efa`(4): ELBOX FastATA 1200 driver.
  - Add a driver for BlizzardPPC 603e+ SCSI.
- amigappc:
  - A CSPPC system with `ahsc`(4) or `cbiiisc`(4) boots into multiuser;
  - Onboard serial now works.
  - `efa`(4): ELBOX FastATA 1200 driver.
- ARM ports(acorn26, acorn32, cats, evbarm, hpcarm, iyonix, netwinder, shark, zaurus):
  - Cortex-A8 CPU support is available.
  - i.MX51 SoC support is available.
- atari:
  - Add support for the SMC Elite Ultra Ethernet with the SMC_TT VME-ISA bridge.
  - Add support for the EtherNEC, ISA NE2000 based Ethernet connected to Atari ROM cartridge slot.
- bebox:
  - Support xserver. Tested on s3(TRIO 64V+).
- cobalt:
  - Add LBA48 support to bootloader so that it can safely load a kernel from NetBSD partition beyond >137GB boundary.
- dreamcast:
  - Fixed a long standing GD-ROM driver bug so that file system on GD-ROM works properly.
  - Build and put a raw binary format kernel into distribution.
  - Switch to using Xorg servers and binaries.
- evbarm:
  -
  - Added support for Gumstix Verdex and Verdex Pro.
  - Support Marvell Sheevaplug and some Marvell SoC NAS boxes.
  - Add initial support for Sharp NetWalker MID.
  - Add driver for OMAP NAND controllers.
  - Add FriendlyARM Mini2440 support.
  - Add initial support for the RaspberryPi. No support yet for the USB controller, the Ethernet interface, or the video chip. Serial console works, and boots multiuser.
- evbmips:
  - Added `voyagerfb`(4) driver, for the Gdium Liberty 1000's video controller.
  - Added support for RMI XLS6ATX_7A board and XL SoC family.

  - Added support for RMI (NetLogic) XLS/XLR models.

- evbppc:
  - Enable builds for OEA, ibm4xx and Book-E modules.
- evbsh3:
  - Add support for Alpha Project MS104-SH4, TAC T-SH7706LAN Rev.3 and TAC T-SH7706LSR Rev.1.
- hp300:
  - Switch NetBSD/hp300 to wscons with rasops.
  - Add support for framebuffers on HP362 and HP382.
  - Add support for Apollo Domain keyboard.
- hp700:
  - Added support for UFS2 boot.
  - pmap update: Support PA 2.0 machines in 32 bit mode. Improve support for machines without the PA7100LC or PA7300LC CPUs.
  - Added `ucas`(9) support for hp700.
  - com at dino now works.
  - `lcd`(4): Driver for hp700 lcds added.
  - Add support for `elroy`(4), `astro`(4), and `ssio`(4) based 64-bit machines running in 32-bit mode.
  - Update `sti`(4) and add `pci`(4) attachment.
  - Add support for HIL devices.
  - Support added for machines with the uturn(4) I/O subsystem.
- hpcarm:
  - Add support for Sharp W-ZERO3 series.
  - Use rtc_offset passed from hpcboot.
  - Bump MAXPARTITIONS from 8 to 16.
  - Switch to using Xorg servers and binaries.
  - Improve console speed on W-ZERO3 machines using write through mapping for framebuffer memory.
  - Improve install on JORNADA720.
- hpcmips:
  - Switch to using Xorg servers and binaries.
- hpcsh:
  - Switch to using Xorg servers and binaries.
  - Add `sysinst`(8) support.

- landisk:
  - Added UFS2 boot support.
  - Enable to build a bootable install disk image.
- luna68k:
  - Enable LUNA to load -current kernels director from firmware.
  - Make SCSI work properly.
  - Use the original OMRON font derived from 4.4BSD-Lite/luna68k rather than gallant19 which is used on Sun workstations.
  - Complete LUNA-II support.
- mac68k:
  - Add timecounter support to the CSI Hurdler Centronics Parallel Interface `cpi`(4) driver.
- macppc:
  - Support new-style `module`(7) kernel modules.
- m68k ports (amiga, atari, cesfic, hp300, luna68k, mac68k, mvme68k, news68k, next68k, sun2, sun3, x68k):
  - Re-enable m68k optimized in_cksum routine.
  - Support `module`(7) loading.
  - Fixed a regression in FPU_EMULATE code that caused weird `awk`(1) behavior.
  - Add hyperbotic and trigonometric functions to m68k FPE.
- mips ports (algor, arc, cobalt, emips, evbmips, ews4800, hpcmips, mipsco, newsmips, pmax, sbmips, sgimips):
  - Added support for 64-bit MIPS processors (O32, N32, N64 ABIs are supported).
  - Added SMP support for MIPS architecture.
  - Rewritten interrupt handling to be much more efficient, added "fast" software interrupts and kernel preemption.
  - Converted MIPS to use PCU to manage FPU.
  - Added MIPS32R2 and MIPS64R2 support.
  - Rework Atheros MIPS-based SoC support. Add initial support for AR71xx (24K) and AR9344 (74K) SoCs
  - Added support for ralink RT3883 SoC from CradlePoint Technologies.
  - Added support for MIPS DSP v2 ASE.
- ofppc:
  - Support Gigabit Ethernet Controller for MV64361 on PegasosII.
  - Support for RDB partitions.
- pmax:

  - Added UFS2 boot support.

- powerpc ports (amigappc, bebox, evbppc, ibmnws, macppc, mvmeppc, ofppc, pmppc, prep, rs6000, sandpoint, walnut):
  - Add support for using secure PLT (thereby allowing data and bss of powerpc programs and shared library to be set non-executable).
  - Added support for Book E Freescale MPC85xx (e500 core) processors. Added "fast" software interrupts support and SOFTFLOAT for PowerPC (Book E only), reworked FPU/VEC support for e500 SPE, other improvements.
  - Converted PowerPC to use PCU to manage FPU/AltiVec/SPE.
  - Initial SMP support for MPC85xx, reworked and unified IPI code, various other improvements.
  - Switch to using direct-mapped uareas (pcb + kernel stacks).
  - The generic PIC code now supports Matt Thomas's fast softintr code.
- prep:
  - Support Xserver. Tested with on-board s3(864).
- sandpoint:
  - Added support for Marvell-SKnet in netboot.
  - D-Link DSM-G600 support.
  - Add support for booting from RAID 1.
  - Iomega Storcenter support.
  - Netronix NH-230/231 and compatible NAS are supported.
- sgimips:
  - Added support for Personal IRIS 4D/20 and 4D/25 (IP6 and IP10).
  - `mec`(4): Added RX hardware checksum support on O2.
  -
- sh3ports (dreamcast, evbsh3, hpcsh, landisk, mmeye):
  - Add some support for SH7706.
- shark:
  - Added support for `module`(7) -style kernel modules.
  - `chipsfb`(4) now works on shark.
- sparc:
  - Switch sparc port to use `wscons`(4)
  - `zx`(4): added `wscons`(4) support.
  - `tcx`(4): support `wsdisplay`(4) and acceleration.
  - `apc`(4): a driver for the Aurora Personality Chip (APC) found on SPARCstation-4/5 and qemu. Allows to idle the CPU when in the idle loop.

  - Re-enable sparc optimized in_cksum routine.
  - Added support for `module`(7) -style kernel modules.
- sparc64:
  - `zx`(4): added `wscons`(4) support.
  - Add a driver for LOMlite lights out management hardware monitor and watchdog timer.
  - Add real UltraSPARC-III* CPU support.
  - Add initial support for Fujitsu SPARC64 systems, not yet stable.
  - `ffb`(4): Added EDID (Extended Display Identification Data) reading, and video mode setting support.
  - Added fast `softint`(9) support.
  - Add support for Enterprise systems (Ex[45]00) systems.
- x68k:
  - Switched `pow`(4) to use `powerd`(8).
  - Fix bootloader failure on X68030+060turbo.
  - Removed pow(4) and rtcalarm(8).
  - `powsw`(4): a revised power switch driver.
- xen:
  - Add PCI pass-through support for Xen3. Dom0 kernel gets a `pciback`(4) driver, to which the device specified in the pciback.hide boot parameter will attach. DomU kernels get a `xpci`(4) driver, to which PCI busses will attach.
  - Added XEN3PAE_DOM0, an i386 dom0 kernel with PAE support. Requires an i386PAE or x86_64 hypervisor.
  - `balloon`(4): Balloon driver now enabled for all Xen kernels.
  - Dropped Xen 2 support. Xen 3.1 or later is now required.
  - Added support for request-rx-copy in the virtual network device backend.
  - Provide experimental support for suspend/resume in NetBSD domUs.
  - Enable no-execute bit feature for i386pae and amd64 kernels.
  - Added support for feature-flush-cache in block device backend, used in block device frontend for DIOCCACHESYNC.
- zaurus:
  - Added zboot.
  - Added playback and recording support to `zaudio`(4).
  - Add Xorg support.
  - Add ioexp driver for SL-C1000.
  - Add PXA25x based Zaurus SL-C700/750/760/860 support.

Userland

- 3rd party software updates:
  - `acpi`(4): ACPICA updated to 20110623.
  - `atf`(7) is version 0.15.
  - ISC `cron`(8) 4.1.
  - OpenSSH version 1.0.1c
  - lvm2tools 2.02.44 and libdevmapper 1.02.30
  - dhcpcd-5.5.4
  - am-utils updated from head; adds UDF support and `-uu`
  - CVS 1.12.13
  - BIND 9.9.1-P4.
  - libbind 6.0-rc1.
  - FSF binutils 2.21.1a.
  - `httpd`(8): bozohttpd-20111118
  - `file`(1) 5.09
  - ntp 4.2.6p5
  - `flex`(1) version 2.5.35.
  - `gcc`(1) version 4.5.3.
  - `gdb`(1) version 7.3.1.
  - GNU MP 5.0.2.
  - `less`(1) version 444.
  - libfetch 2.23
  - Lua 5.1.4
  - OpenLDAP 2.4.23
  - SQLite 3.6.9
  - `tmux`(1) 1.5
  - trousers-0.3.8; tmp-tools 1.3.7.1
  - `xz`(1) 5.0.0
  - byacc-20110908
  - tzdata2011n
  - `dns-sd`(1): Import mDNSResponder 212.1.
- Libraries:
  - libc:

- Add new ptree (Patricia / RADIX tree) implementation.
- Added `fopendir`(3).
- Added RFC 2045 MIME Quoted-Printable support.
- Added `glob_pattern_p`(3).
- Added `memrchr`(3).
- Added `stpcpy`(3), `stpncpy`(3), and `strnlen`(3).
- Added %s (seconds since the Epoch) to `strptime`(3), for symmetry with `strftime`(3).
- Added the getdate(3) and getdate_err value, conforming to IEEE Std 1003.1 ("POSIX.1") and the Open Group Base Specifications X/Open System Interfaces extension ("XSI").
- Added `getdelim`(3) and `getline`(3).
- Added `posix_spawn`(3).
- Added a space-efficient write-once database (`cdbr`(3), `cdbw`(3)).
- Provide a re-entrant and thread-safe set of timezone APIs that don't require locking and can operate on user-specified timezones.

– libm: Add f{dim,max,min}{,f,l} from FreeBSD.

– Replaced termcap with `terminfo`(3).

– perfuse: Add the PUFFS RElay to FUSE library, which bridges the kernel level API for FUSE filesystems with native PUFFS.

– `rump`(3)

- Moved VFS functionality from librump to a new library, librumpvfs.
- Added support for remote system calls.
- Add IPv6 support to rumpnet.
- Support kernel config framework and devices in rumpdev.
- rumpfs: support registering exernal files which are accessed from the host OS file system namespace instead of from within the rump virtual kernel.
- rumpvfs: Use the unmodified kernel vnode pager.

– `bluetooth`(3): updated the Bluetooth service discovery API and merged it into libbluetooth, retiring the separate libsdp.

- Installer (sysinst):
  – Default to `wapbl`(4) logging for UFS partitions.
  – Make sure the installer rejects UFS2 for root partitions on ports whose bootloaders don't support booting from UFS2.
- Changes to the way `make`(1) processes `.for` loops.

- makefs(8): Added support for encoding RISC OS metadata into ISO9660 file systems.
- mount(8): Added −o rump , which mounts the file system as a userspace server via puffs(4) and rump(3) instead of using a kernel drver.
- dkctl(8): Display cache, strategy and list of wedges if no command is specified on the command line.
- ar(1): Added support for "deterministic mode"

- Added crash(8), a new utility to debug kernel images, based on the in-kernel debugger, ddb(4).
- eject(1) now has amd(8) support.
- mtree(8): add -S option to sort entries.
- Imported netpgp(1), a BSD-licensed PGP implementation.
- install(1): Added support for writing sha256, sha384, or sha512 hashes to a METALOG.
- rpcgen(1): Added support for hyper and quad keywords.
- New wakeonlan(8) command to send Wake-on-LAN packets to machines on the local Ethernet.
- Added nbperf(1), a minimal perfect hash function generator.
- unzip(1): a libarchive-based unzip frontend.
- apropos(1): new implementation using SQLite Full Text Index.
- audiocfg(1): new tool to control audio defaults.
- devpubd(8): Add a device publishing daemon for automatic device node creation.
- disklabel(8): Disable COMPAT_386BSD_MBRPART.
- dkctl(8): Display cache, strategy, and list of wedges if no command is specified in the command line.
- fincore(1): Add a utility to query file cache.
- ifconfig(8): Add the linkstr command which can be used to communicate an arbitrary string with the interface driver.
- man(1): display a manpage when specified with a path.
- mkubootimage(1): Added a tool to generate u-boot kernel images.

Besides this list, there have also been innumerable bug fixes and miscellaneous enhancements.

Components removed from NetBSD

In this release of NetBSD, the following software components have been removed from the system. Some were not useful anymore, or their utility did not justify the maintenance overhead. Others were not working properly and there was a lack of interest in fixing them.

- Support for Xen 2 has been dropped. Xen 3.1 or later is now required to run NetBSD.
- Support for LKMs (Loadable Kernel Modules) was dropped; use the new module(7) framework.
- "softdep"

  support is no longer available in FFS; use wapbl(4) logging instead.
- The

  playstation2:

http://www.NetBSD.org/ports/playstation2/
port.

- tn3270 was removed from base; it is available in pkgsrc.
- Support for Darwin, Mach, IRIX and PECOFF emulation was retired.

Features to be removed in a later release
The following features are to be removed from NetBSD in the future:

- `dhclient`(8) and `rtsol`(8) in favor of `dhcpcd`(8).
- `groff`(1) is being phased out. Man pages are handled with `mandoc`(1), and `groff`(1) can still be found in pkgsrc as `textproc/groff`.
- `kame_ipsec`(4) has been replaced by `fast_ipsec`(4). The option to use the old implementation (see `options`(4)) will be removed in the next NetBSD release.

The NetBSD Foundation
The NetBSD Foundation is a tax exempt, not-for-profit 501(c)(3) corporation that devotes itself to the traditional goals and Spirit of the NetBSD Project and owns the trademark of the word "NetBSD". It supports the design, development, and adoption of NetBSD worldwide. More information on the NetBSD Foundation, its composition, aims, and work can be found at: **http://www.NetBSD.org/foundation/**

Sources of NetBSD
Refer to **http://www.NetBSD.org/mirrors/**

NetBSD 6.0 Release Contents
The root directory of the NetBSD 6.0 release is organized as follows:

`.../NetBSD-6.0/`

`CHANGES`	Changes between the 5.0 and 6.0 releases.
`CHANGES-6.0`	Changes between the initial 6.0 branch and final release of 6.0.
`CHANGES.prev`	Changes in previous NetBSD releases.
`LAST_MINUTE`	Last minute changes and notes about the release.
`README.files`	README describing the distribution's contents.
`source/`	Source distribution sets; see below.

In addition to the files and directories listed above, there is one directory per architecture, for each of the architectures for which NetBSD 6.0 has a binary distribution.

The source distribution sets can be found in subdirectories of the `source` subdirectory of the distribution tree. They contain the complete sources to the system. The source distribution sets are as follows:

gnusrc	This set contains the "gnu" sources, including the source for the compiler, assembler, groff, and the other GNU utilities in the binary distribution sets.
sharesrc	This set contains the "share" sources, which include the sources for the man pages not associated with any particular program; the sources for the typesettable document set; the dictionaries; and more.
src	This set contains all of the base NetBSD 6.0 sources which are not in **gnusrc**, **sharesrc**, or **syssrc**.

syssrc This set contains the sources to the NetBSD 6.0 kernel for all architectures as well as the `config`(1) utility.

xsrc This set contains the sources to the X Window System.

All the above source sets are located in the `source/sets` subdirectory of the distribution tree.

The source sets are distributed as compressed tar files. Except for the **pkgsrc** set, which is traditionally unpacked into `/usr/pkgsrc`, all sets may be unpacked into `/usr/src` with the command:

```
# cd / ; tar -zxpf set_name.tgz
```

In each of the source distribution set directories, there are files which contain the checksums of the files in the directory:

`MD5` MD5 digests in the format produced by the command:
cksum -a MD5 *file*.

`SHA512` SHA512 digests in the format produced by the command:
cksum -a SHA512 *file*.

The SHA512 digest is safer, but MD5 checksums are provided so that a wider range of operating systems can check the integrity of the release files.

NetBSD/evbarm subdirectory structure

The evbarm-specific portion of the NetBSD 6.0 release is found in the `evbarm` subdirectory of the distribution: `.../NetBSD-6.0/evbarm/`. It contains the following files and directories:

`INSTALL.html`
`INSTALL.ps`
`INSTALL.txt`
`INSTALL.more` Installation notes in various file formats, including this file. The `.more` file contains underlined text using the `more`(1) conventions for indicating italic and bold display.

`binary/`
`kernel/`
`netbsd-GENERIC.gz`
A gzipped NetBSD kernel containing code for everything supported in this release.
`sets/` evbarm binary distribution sets; see below.

`installation/`
`misc/` Miscellaneous evbarm installation utilities; see installation section below.

Binary distribution sets

The NetBSD evbarm binary distribution sets contain the binaries which comprise the NetBSD 6.0 release for evbarm. The binary distribution sets can be found in the `evbarm/binary/sets` subdirectory of the NetBSD 6.0 distribution tree, and are as follows:

base The NetBSD 6.0 evbarm **base** binary distribution. You *must* install this distribution set. It contains the base NetBSD utilities that are necessary for the system to run and be minimally functional.

comp Things needed for compiling programs. This set includes the system include files (`/usr/include`) and the various system libraries (except the shared libraries, which are included as part of the **base** set). This set also includes the manual pages for all of the utilities it contains, as well as the system call and library manual pages.

etc This distribution set contains the system configuration files that reside in `/etc` and in several other places. This set *must* be installed if you are installing the system from scratch, but should *not* be used if you are upgrading.

games This set includes the games and their manual pages.

kern-INTEGRATOR
(see below)

kern-IQ80310
(see below)

kern-IQ80321
(see below)

kern-TEAMASA_NPWR

These sets contain a NetBSD/evbarm 6.0 kernel, named `/netbsd`. Some of these sets also contain a binary format kernel named `/netbsd.bin` and an S-record format kernel named `/netbsd.srec` that your firmware may need to boot. You *must* install the kernel that matches your hardware.

man This set includes all of the manual pages for the binaries and other software contained in the **base** set. Note that it does not include any of the manual pages that are included in the other sets.

misc This set includes the system dictionaries, the typesettable document set, and other files from `/usr/share`.

text This set includes NetBSD's text processing tools, including `groff`(1), all related programs, and their manual pages.

NetBSD maintains its own set of sources for the X Window System in order to assure tight integration and compatibility. These sources are based on X.Org. Binary sets for the X Window System are distributed with NetBSD. The sets are:

xbase The basic files needed for a complete X client environment. This does not include the X servers.

xcomp The extra libraries and include files needed to compile X source code.

xfont Fonts needed by the X server and by X clients.

xetc Configuration files for X which could be locally modified.

xserver The X server.

The evbarm binary distribution sets are distributed as gzipped tar files named with the extension **.tgz**, e.g. `base.tgz`.

The instructions given for extracting the source sets work equally well for the binary sets, but it is worth noting that if you use that method, the filenames stored in the sets are relative and therefore the files are extracted *below the current directory*. Therefore, if you want to extract the binaries into your system, i.e. replace the system binaries with them, you have to run the **`tar -xzpf`** command from the root directory (`/`) of your system.

Note: Each directory in the evbarm binary distribution also has its own checksum files, just as the source distribution does.

NetBSD/evbarm System Requirements and Supported Devices

NetBSD 6.0 runs on the following ARM architecture evaluation boards:

- Technologic Systems TS-7200
- ARM, Ltd. Integrator
- Intel IQ80310
- Intel IQ80321
- Team ASA, Inc. Npwr
- Intel IXM1200
- Samsung SMDK2800
- ADI Engineering, Inc. BRH ("Big Red Head")
- Arcom Viper

Supported devices (Technologic Systems TS-7200)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- TS-5620 Real Time Clock
- Serial ports
  - On-chip EP9302 UARTs
  - TS-SER1, TS-SER2, TS-SER4 PC/104 serial adapters
  - TS-MODEM, TS-MODEM2 PC/104 land-line/cellular modems
- Ethernet adapters
  - On-chip EP9302 10/100 ethernet
  - TS-ETH10 PC/104 expansion ethernet adapters
- Other on-board functions
  - CompactFlash socket
  - USB OHCI host
  - Text-mode HD44780 LCD display header
  - Matrix keypad/GPIO header
  - Board temperature sensor and watchdog timer

Supported devices (ARM, Ltd. Integrator)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- PrimeCell PL030 Real Time Clock
- Serial ports
  - PrimeCell PL010 UART
- SCSI host adapters
  - Adaptec AHA-2910, 2915, 2920, and 2930C adapters.
  - Adaptec AHA-2x4x[U][2][W] cards and onboard PCI designs using the AIC-7770, AIC-7850, AIC-7860, AIC-7870, AIC-7880 and AIC-789x chipsets.
  - Adaptec AHA-394x[U][W] cards [b]

  - Adaptec AHA-3950U2 cards
  - Adaptec AHA-3960, 19160 and 29160 Ultra-160 adapters

- Ethernet adapters
  - Intel i82557, i82558, i82559, i82550

Supported devices (Intel IQ80310)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- Serial ports
  - On-board ST16c550 UARTs
- Ethernet adapters
  - Intel i82557, i82558, i82559, i82550
- i80312 Companion I/O functions
  - General Purpose I/O unit

Supported devices (Intel IQ80321)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- Serial ports
  - On-board TI 16550 UART
- Ethernet adapters
  - Intel i82542, i82543, i85244 Gigabit Ethernet
- i80321 I/O Processor functions
  - Application Accelerator Unit
  - Watchdog timer

Supported devices (Team ASA Npwr)

The Npwr is a storage appliance based on the Intel IOP310 I/O processor chipset. This is an exhaustive list of devices supported on the Npwr as the Npwr has no expansion capability.

- Serial ports
  - On-board TI 16550 UART
- SCSI host adapters
  - On-board LSI Logic 53c1010 Ultra160 SCSI adapter
- Ethernet adapters
  - On-board Intel i82544 Gigabit Ethernet

Supported devices (Intel IXM1200)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- Serial ports
  - IXP1200 on-chip serial port
- Ethernet adapters

- Intel i82557, i82558, i82559, i82550

Supported devices (Samsung SMDK2800)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- Serial ports
  - S3C2800 on-chip serial ports

Supported devices (ADI BRH)

For devices that have machine-independent drivers, this is not an exhaustive list, but merely reflects the devices that have been tested on this platform.

- Serial ports
  - On-board TI 16752 DUART
- Ethernet adapters
  - Intel i82557, i82558, i82559, i82550
  - Intel i82544, i82546 Gigabit Ethernet

Supported devices (Arcom Viper)

Current this is an exhaustive list, since expansion ports such as PC/104 and USB are not yet supported.

- Serial ports
  - On-chip PXA255 UARTs

  Ethernet adapters
  - On-board SMC91C111

Getting the NetBSD System on to Useful Media

Installation is supported from several media types, including:

- CD-ROM / DVD
- FTP
- Remote NFS partition
- Tape
- Existing NetBSD partitions, if performing an upgrade

The steps necessary to prepare the distribution sets for installation depend upon which installation medium you choose. The steps for the various media are outlined below.

CD-ROM / DVD Find out where the distribution set files are on the CD-ROM or DVD. Likely locations are `binary/sets` and `evbarm/binary/sets`.

Proceed to the instructions on installation.

FTP The preparations for this installation/upgrade method are easy; all you need to do is make sure that there's an FTP site from which you can retrieve the NetBSD distribution when you're about to install or upgrade. If you don't have DHCP available on your network, you will need to know the numeric IP address of that site, and, if it's not on a network directly connected to the machine on which you're installing or upgrading NetBSD, you need to know the numeric IP address of the router closest to the NetBSD machine. Finally, you need to know the numeric IP address of the NetBSD machine itself.

Once you have this information, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

NFS

Place the NetBSD distribution sets you wish to install into a directory on an NFS server, and make that directory mountable by the machine on which you are installing or upgrading NetBSD. This will probably require modifying the `/etc/exports` file on the NFS server and resetting its mount daemon (mountd). (Both of these actions will probably require superuser privileges on the server.)

You need to know the numeric IP address of the NFS server, and, if you don't have DHCP available on your network and the server is not on a network directly connected to the machine on which you're installing or upgrading NetBSD, you need to know the numeric IP address of the router closest to the NetBSD machine. Finally, you need to know the numeric IP address of the NetBSD machine itself.

Once the NFS server is set up properly and you have the information mentioned above, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

Tape

To install NetBSD from a tape, you need to make a tape that contains the distribution set files, in 'tar' format.

If you're making the tape on a UNIX-like system, the easiest way to do so is probably something like:

```
# tar -cf tape_device dist_directories
```

where *tape_device* is the name of the tape device that describes the tape drive you're using; possibly `/dev/rst0`, or something similar, but it will vary from system to system. (If you can't figure it out, ask your system administrator.) In the above example, *dist_directories* are the distribution sets' directories, for the distribution sets you wish to place on the tape. For instance, to put the **kern-GENERIC, base,** and **etc** distributions on tape (in order to do the absolute minimum installation to a new disk), you would do the following:

```
# cd .../NetBSD-6.0
# cd evbarm/binary
# tar -cf tape_device kern-GENERIC base etc
```

Note: You still need to fill in *tape_device* in the example.

Once you have the files on the tape, you can proceed to the next step in the installation or upgrade process. If you're installing NetBSD from scratch, go to the section on preparing your hard disk, below. If you're upgrading an existing installation, go directly to the section on upgrading.

Preparing your System for NetBSD installation

First and foremost, before beginning the installation process, *make sure you have a reliable backup* of any data on the target system that you wish to keep. Mistakes in partitioning may lead to data loss.

Preparation for the Technologic Systems TS-7200

The TS-7200 uses RedBoot firmware which supports loading the kernel via serial port and the on-chip Ethernet. These notes assume that the Ethernet will be used to load the kernel. RedBoot can either use TFTP or HTTP to load the kernel via the network.

These notes also assume the the TS-7200 will be run from the CompactFlash; that a FFS filesystem on the CompactFlash card will provide the root file system. The minimum size of the CompactFlash card is 64MB with 512MB being the recommended minimum size if attempting a full installation.

The first step to install NetBSD is to interrupt normal system bootup and drop to the RedBoot prompt by hitting Ctrl-C immediately after applying power. To load both the installation kernel and the generic post-installation TS7200 kernel you will need network connectivity from RedBoot which you will have to configure using the RedBoot **fconfig** command; see the RedBoot documentation for more information.

A compressed kernel image and loader suitable for placing into flash is provided with the distribution. Use of this image is optional; a kernel that can be directly loaded over the network by RedBoot is also provided.

The image for the TS-7200 can be found under the NetBSD/evbarm 6.0 distribution directory in `evbarm/binary/gzimg/gzimg_TS7200_flash_0x60660000.gz`, and corresponds to the kernel in `evbarm/binary/kernel/netbsd-TS7200.gz`. The following steps describe how to copy the compressed kernel image into flash.

1. Uncompress the gzimg file and place it into the TFTP server's download area (note, the kernel inside the gzimg is still compressed after this step).

   ```
   server# gzcat gzimg_TS7200_flash_0x60660000.gz > /tftpboot/gzimg_TS7200_flash_0x60660000
   ```

2. Load the gzimg from the TFTP server.

   ```
   RedBoot> load -r -b 0x00200000 gzimg_TS7200_flash_0x60660000
   Raw file loaded 0x00200000-0x00605fe0
   ```

3. Use the RedBoot **fis** command to copy the image into flash. For more information on the RedBoot Flash Image System, see the RedBoot documentation. The factory default Linux image may already be present in flash and must be deleted before continuing.

   ```
   RedBoot> fis delete vmlinux
   RedBoot> fis create -b 0x00200000 -f 0x60660000 -l 0x00160000 netbsd.gz
   ```

Once the compressed kernel image has been copied into flash, it may be started by jumping to the flash address of the image:

```
RedBoot> g 0x60660000
```

Preparation for the Intel IQ80310

The IQ80310 uses RedBoot firmware from Red Hat, Inc. RedBoot supports loading the kernel via the serial port and the on-board Ethernet. These notes assume that the Ethernet will be used to load the kernel. RedBoot uses the Trivial File Transfer Protocol (TFTP) to load the kernel via the network.

These notes also assume that the IQ80310 will be run as a diskless system; that an NFS server will provide the root file system. The NetBSD kernel uses the Dynamic Host Configuration Protocol (DHCP) to obtain network address and root file system information.

The first step is to configure your DHCP, NFS, and TFTP server software. You will need the MAC address for the on-board Ethernet, which RedBoot can provide; see the RedBoot documentation for more information.

The next step is to configure RedBoot to obtain its IP address from your DHCP server; see the RedBoot documentation for more information.

Once your DHCP server and RedBoot are properly configured, you should see information similar to the following when the IQ80310 is reset or powered-up:

```
RedBoot(tm) debug environment - built 17:16:14, Feb 12 2001
Platform: IQ80310 (XScale)
Copyright (C) 2000, Red Hat, Inc.
```

```
RAM: 0xa0000000-0xa2000000
FLASH: 0x00000000 - 0x00800000, 64 blocks of 0x00020000 bytes each.
IP: 192.168.0.10, Default server: 192.168.0.1
RedBoot>
```

A compressed kernel image and loader suitable for placing into flash is provided with the distribution. Use of this image is optional; a kernel that can be directly loaded over the network by RedBoot is also provided.

The image for the IQ80310 can be found under the NetBSD/evbarm 6.0 distribution directory in `evbarm/binary/gzimg/gzimg_IQ80310_flash_0x00080000.gz`, and corresponds to the kernel in `evbarm/binary/kernel/netbsd-IQ80310.gz`. The following steps describe how to copy the compressed kernel image into flash.

1. Uncompress the gzimg file and place it into the TFTP server's download area (note, the kernel inside the gzimg is still compressed after this step).

   ```
   server# gzcat gzimg_IQ80310_flash_0x00080000.gz > /tftpboot/gzimg_IQ80310_flash_0x00080000
   ```

2. Load the gzimg from the TFTP server.

   ```
   RedBoot> load -r -b 0xa0200000 gzimg_IQ80310_flash_0x00080000
   Raw file loaded 0xa0200000-0xa0305fe0
   ```

3. Use the RedBoot **fis** command to copy the image into flash. For more information on the RedBoot Flash Image System, see the RedBoot documentation.

   ```
   RedBoot> fis create -b 0xa0200000 -f 0x00080000 -l 0x00200000 netbsd.gz
   ... Erase from 0x00080000-0x00280000: ..................
   ... Program from 0xa0200000-0xa0400000 at 0x00080000: .....................
   ... Unlock from 0x007e0000-0x00800000:.
   ... Erase from 0x007e0000-0x00800000:.
   ... Program from 0xa1fd0000-0xa1ff0000 at 0x007e0000:.
   ... Lock from 0x007e0000-0x00800000:.
   ```

Once the compressed kernel image has been copied into flash, it may be started by jumping to the flash address of the image:

```
RedBoot> g 0x00080000

>> NetBSD/IQ80310 Gzip Boot, Revision 1.1
>> (root@tgm, Thu Mar 28 18:32:45 PST 2002)
>> RAM 0xa0000000 - 0xaffffffff, heap at 0xaffd0000
>> Load address: 0xa0200000
>> Image size: 741244
Uncompressing image...done.
Jumping to image @ 0xa0200000...

NetBSD/evbarm (IQ80310) booting ...
Resetting secondary PCI bus...
initarm: Configuring system ...
physmemory: 65536 pages at 0xa0000000 -> 0xaffffffff
init subsystems: stacks vectors undefined pmap irq done.
[ using 155084 bytes of netbsd ELF symbol table ]
Copyright (c) 1996, 1997, 1998, 1999, 2000, 2001, 2002
    The NetBSD Foundation, Inc.  All rights reserved.
Copyright (c) 1982, 1986, 1989, 1991, 1993
```

```
    The Regents of the University of California.  All rights reserved.

NetBSD 1.5ZC (IQ80310) #20: Fri Mar 29 10:25:53 PST 2002
    root@tgm:/u1/netbsd/src/sys/arch/evbarm/compile/IQ80310
total memory = 256 MB
avail memory = 232 MB
using 1228 buffers containing 13208 KB of memory
mainbus0 (root)
cpu0 at mainbus0: i80200 step A-0 (XScale core)
cpu0: DC enabled IC enabled WB enabled LABT
cpu0: 32KB/32B 32-way Instruction cache
cpu0: 32KB/32B 32-way write-back-locking Data cache
obio0 at mainbus0: board rev. F, CPLD rev. D, backplane present
com0 at obio0 addr 0xfe810000: ns16550a, working fifo
com0: console
com1 at obio0 addr 0xfe800000: ns16550a, working fifo
iopxs0 at mainbus0: i80312 Companion I/O, acting as PCI host
iopxs0: configuring Secondary PCI bus
pci0 at iopxs0 bus 1
pci0: i/o space, memory space enabled
ppb0 at pci0 dev 7 function 0: Digital Equipment DECchip 21154 PCI-PCI Bridge (rev. 0
pci1 at ppb0 bus 2
pci1: i/o space, memory space enabled
fxp0 at pci1 dev 0 function 0: i82559S Ethernet, rev 9
fxp0: interrupting at iq80310 irq 1
fxp0: Ethernet address 00:80:4d:46:0b:b9
inphy0 at fxp0 phy 1: i82555 10/100 media interface, rev. 4
inphy0: 10baseT, 10baseT-FDX, 100baseTX, 100baseTX-FDX, auto
clock: hz=100 stathz=0 profhz=0
boot device: <unknown>
root device:
```

Preparation for the Intel IQ80321

The IQ80321 uses RedBoot firmware from Red Hat, Inc. RedBoot supports loading the kernel via the serial port and the on-board Ethernet. These notes assume that the Ethernet will be used to load the kernel. RedBoot uses the Trivial File Transfer Protocol (TFTP) to load the kernel via the network.

These notes also assume that the IQ80321 will be run as a diskless system; that an NFS server will provide the root file system. The NetBSD kernel uses the Dynamic Host Configuration Protocol (DHCP) to obtain network address and root file system information.

The first step is to configure your DHCP, NFS, and TFTP server software. You will need the MAC address for the on-board Ethernet, which RedBoot can provide; see the RedBoot documentation for more information.

The next step is to configure RedBoot to obtain its IP address from your DHCP server; see the RedBoot documentation for more information.

Once your DHCP server and RedBoot are properly configured, you should see information similar to the following when the IQ80321 is reset or powered-up:

```
Ethernet eth0: MAC address 00:07:e9:03:38:40
IP: 192.168.0.11, Default server: 192.168.0.1
```

```
RedBoot(tm) bootstrap and debug environment [ROM]
Non-certified release, version UNKNOWN - built 11:21:56, Feb  1 2002

Platform: IQ80321 (XScale)
Copyright (C) 2000, 2001, 2002, Red Hat, Inc.

RAM: 0x00000000-0x08000000, 0x00017008-0x01ddd000 available
FLASH: 0xf0000000 - 0xf0800000, 64 blocks of 0x00020000 bytes each.
RedBoot>
```

A compressed kernel image and loader suitable for placing into flash is provided with the distribution. Use of this image is optional; a kernel that can be directly loaded over the network by RedBoot is also provided.

The image for the IQ80321 can be found under the NetBSD/evbarm 6.0 distribution directory in `evbarm/binary/gzimg/gzimg_IQ80321_flash_0xf0080000.gz`, and corresponds to the kernel in `evbarm/binary/kernel/netbsd-IQ80321.gz`. The following steps describe how to copy the compressed kernel image into flash.

1. Uncompress the gzimg file and place it into the TFTP server's download area (note, the kernel inside the gzimg is still compressed after this step).

   ```
   server# gzcat gzimg_IQ80321_flash_0xf0080000.gz > /tftpboot/gzimg_IQ80321_flash_0xf0080000
   ```

2. Load the gzimg from the TFTP server.

   ```
   RedBoot> load -r -b 0x00200000 gzimg_IQ80321_flash_0xf0080000
   Raw file loaded 0x00200000-0x00305fe4
   ```

3. Use the RedBoot **fis** command to copy the image into flash. For more information on the RedBoot Flash Image System, see the RedBoot documentation.

   ```
   RedBoot> fis create -b 0x00200000 -f 0xf0080000 -l 0x00200000 netbsd.gz
   * CAUTION * about to program 'netbsd.gz'
               at 0xf0080000..0xf027ffff from 0x00200000 - are you sure (y/n)? y
   ... Erase from 0xf0080000-0xf0280000: ......................
   ... Program from 0x00200000-0x00400000 at 0xf0080000: .....................
   ... Unlock from 0xf07e0000-0xf0800000:.
   ... Erase from 0xf07e0000-0xf0800000:.
   ... Program from 0x01ddf000-0x01dff000 at 0xf07e0000:.
   ... Lock from 0xf07e0000-0xf0800000:.
   ```

Once the compressed kernel image has been copied into flash, it may be started by jumping to the flash address of the image:

```
RedBoot> g 0xf0080000

>> NetBSD/IQ80321 Gzip Boot, Revision 1.1
>> (root@tgm, Thu Mar 28 18:32:45 PST 2002)
>> RAM 0xa0000000 - 0xa7ffffff, heap at 0xa7fd0000
>> Load address: 0xa0200000
>> Image size: 739495
Uncompressing image...done.
Jumping to image @ 0xa0200000...

NetBSD/evbarm (IQ80321) booting ...
initarm: Configuring system ...
```

```
physmemory: 32768 pages at 0xa0000000 -> 0xa7ffffff
init subsystems: stacks vectors undefined pmap irq done.
[ using 155076 bytes of netbsd ELF symbol table ]
Copyright (c) 1996, 1997, 1998, 1999, 2000, 2001, 2002
    The NetBSD Foundation, Inc.  All rights reserved.
Copyright (c) 1982, 1986, 1989, 1991, 1993
    The Regents of the University of California.  All rights reserved.

NetBSD 1.5ZC (IQ80321) #1: Thu Mar 28 18:31:58 PST 2002
    root@tgm:/u1/netbsd/src/sys/arch/evbarm/compile/IQ80321
total memory = 128 MB
avail memory = 113 MB
using 1228 buffers containing 6656 KB of memory
mainbus0 (root)
cpu0 at mainbus0: i80321 step A-0 (XScale core)
cpu0: DC enabled IC enabled WB enabled LABT
cpu0: 32KB/32B 32-way Instruction cache
cpu0: 32KB/32B 32-way write-back-locking Data cache
obio0 at mainbus0
com0 at obio0 addr 0xfe800000: ns16550a, working fifo
com0: console
iopxs0 at mainbus0: i80321 I/O Processor, acting as PCI host
iopxs0: configuring PCI bus
pci0 at iopxs0 bus 0
pci0: i/o space, memory space enabled, rd/line, rd/mult, wr/inv ok
wm0 at pci0 dev 4 function 0: Intel i82544 1000BASE-T Ethernet, rev. 2
wm0: interrupting at iop321 irq 27
wm0: Ethernet address 00:07:e9:03:38:40
makphy0 at wm0 phy 1: Marvell 88E1000 Gigabit PHY, rev. 0
makphy0: 10baseT, 10baseT-FDX, 100baseTX, 100baseTX-FDX, 1000baseT, 1000baseT-FDX, au
clock: hz=100 stathz=0 profhz=0
boot device: <unknown>
root device:
```

Installing the NetBSD System

Installation for the Technologic Systems TS-7200

The following steps describe how to set up a CompactFlash card for the TS-7200. The TS-7200 can use the interactive installation program **sysinst** to perform an internet installation from ftp.netbsd.org on the CompactFlash.

1. Place the netbsd-TS7200_INSTALL.bin kernel into the TFTP server's download area. It must be decompressed from the gzipped image in the release directory evbarm/installation/instkernel/netbsd-TS7200_INSTALL.srec.gz

   ```
   server# gunzip netbsd-TS7200_INSTALL.srec.gz
   server# cp netbsd-TS7200_INSTALL.srec
   /tftpboot/netbsd-TS7200_INSTALL
   ```

2. Load the kernel from the TFTP server.

   ```
   RedBoot> load netbsd-TS7200_INSTALL
   ```

3. Start the kernel running.

   ```
   RedBoot> go
   ```

   The kernel will display boot messages, probe for devices, and invoke the interactive sysinst installation tool. Once sysinst has completed installation, the system will reboot back into RedBoot. If the preparation instructions above have been followed, the post-installation NetBSD kernel will be in the FIS ready to be jumped into. You can have RedBoot automatically start NetBSD by putting the command **go 0x60660000** into the RedBoot bootscript using the **fconfig** command.

Installation for the Intel IQ80310

The following steps describe how to set up an NFS root environment for the IQ80310 and how to boot the IQ80310.

1. Place the kernel into the TFTP server's download area.

   RedBoot only loads S-Records, so select a kernel with the ".srec" filename suffix. In this example, we will boot the kernel hard-wired to use the on-board Ethernet as the root device.

   ```
   server# cp netbsd-fxp0.srec /tftpboot/netbsd-iq80310-fxp0
   ```

2. Unpack the distribution sets into the target's root directory.

   ```
   server# cd /export/client/iq80310
   server# gzcat .../base.tgz | tar xvpf -
   server# gzcat .../etc.tgz | tar xvpf -
   [repeat for all sets you wish to unpack]
   ```

3. Load the kernel from the TFTP server.

   ```
   RedBoot> load netbsd-iq80310-fxp0
   Entry point: 0xa0200000, address range: 0xa0200000-0xa035e07c
   RedBoot>
   ```

4. Start the kernel running. The kernel will display boot message, probe for devices, and mount the root file system. If you used a kernel hard-wired to use the on-board Ethernet, it will attempt to mount the root file system automatically. Otherwise, it will prompt for the root device to use.

   Since the system's run-time environment has not yet been configured, the system should boot into single-user mode.

   ```
   RedBoot> go

   NetBSD/evbarm (IQ80310) booting ...
   Resetting secondary PCI bus...
   initarm: Configuring system ...
   physmemory: 65536 pages at 0xa0000000 -> 0xaffffffff
   init subsystems: stacks vectors undefined pmap irq done.
   [ using 155084 bytes of netbsd ELF symbol table ]
   Copyright (c) 1996, 1997, 1998, 1999, 2000, 2001, 2002
       The NetBSD Foundation, Inc.  All rights reserved.
   Copyright (c) 1982, 1986, 1989, 1991, 1993
       The Regents of the University of California.  All rights reserved.

   NetBSD 1.5ZC (IQ80310) #20: Fri Mar 29 10:25:53 PST 2002
       root@tgm:/u1/netbsd/src/sys/arch/evbarm/compile/IQ80310
   total memory = 256 MB
   avail memory = 232 MB
   ```

```
using 1228 buffers containing 13208 KB of memory
mainbus0 (root)
cpu0 at mainbus0: i80200 step A-0 (XScale core)
cpu0: DC enabled IC enabled WB enabled LABT
cpu0: 32KB/32B 32-way Instruction cache
cpu0: 32KB/32B 32-way write-back-locking Data cache
obio0 at mainbus0: board rev. F, CPLD rev. D, backplane present
com0 at obio0 addr 0xfe810000: ns16550a, working fifo
com0: console
com1 at obio0 addr 0xfe800000: ns16550a, working fifo
iopxs0 at mainbus0: i80312 Companion I/O, acting as PCI host
iopxs0: configuring Secondary PCI bus
pci0 at iopxs0 bus 1
pci0: i/o space, memory space enabled
ppb0 at pci0 dev 7 function 0: Digital Equipment DECchip 21154 PCI-PCI Bridge (rev
pci1 at ppb0 bus 2
pci1: i/o space, memory space enabled
fxp0 at pci1 dev 0 function 0: i82559S Ethernet, rev 9
fxp0: interrupting at iq80310 irq 1
fxp0: Ethernet address 00:80:4d:46:0b:b9
inphy0 at fxp0 phy 1: i82555 10/100 media interface, rev. 4
inphy0: 10baseT, 10baseT-FDX, 100baseTX, 100baseTX-FDX, auto
clock: hz=100 stathz=0 profhz=0
boot device: <unknown>
root on fxp0
nfs_boot: trying DHCP/BOOTP
nfs_boot: DHCP next-server: 192.168.0.1
nfs_boot: my_name=iq80310.lab.wasabisystems.com
nfs_boot: my_domain=wasabisystems.com
nfs_boot: my_addr=192.168.0.10
nfs_boot: my_mask=255.255.255.0
nfs_boot: gateway=192.168.0.254
root on 192.168.0.1:/export/client/iq80310
/etc/rc.conf is not configured.  Multiuser boot aborted.
Enter pathname of shell or RETURN for sh:
```

Installation for the Intel IQ80321

The following steps describe how to set up an NFS root environment for the IQ80321 and how to boot the IQ80321.

1. Place the kernel into the TFTP server's download area.

   RedBoot only loads S-Records, so select a kernel with the ".srec" filename suffix. In this example, we will boot the kernel hard-wired to use the on-board Ethernet as the root device.

   ```
   server# cp netbsd-wm0.srec /tftpboot/netbsd-iq80321-wm0
   ```

2. Unpack the distribution sets into the target's root directory.

   ```
   server# cd /export/client/iq80321
   server# gzcat .../base.tgz | tar xvpf -
   server# gzcat .../etc.tgz | tar xvpf -
   [repeat for all sets you wish to unpack]
   ```

3. Load the kernel from the TFTP server.

```
RedBoot> load netbsd-iq80321-wm0
Entry point: 0x00200000, address range: 0x00200000-0x00396a40
RedBoot>
```

4. Start the kernel running. The kernel will display boot message, probe for devices, and mount the root file system. If you used a kernel hard-wired to use the on-board Ethernet, it will attempt to mount the root file system automatically. Otherwise, it will prompt for the root device to use.

   Since the system's run-time environment has not yet been configured, the system should boot into single-user mode.

```
RedBoot> go

NetBSD/evbarm (IQ80321) booting ...
initarm: Configuring system ...
physmemory: 32768 pages at 0xa0000000 -> 0xa7ffffff
init subsystems: stacks vectors undefined pmap irq done.
[ using 156468 bytes of netbsd ELF symbol table ]
Copyright (c) 1996, 1997, 1998, 1999, 2000, 2001, 2002
    The NetBSD Foundation, Inc.  All rights reserved.
Copyright (c) 1982, 1986, 1989, 1991, 1993
    The Regents of the University of California.  All rights reserved.

NetBSD 1.5ZC (IQ80321) #1: Thu Mar 28 18:20:34 PST 2002
    root@tgm:/u1/netbsd/src/sys/arch/evbarm/compile/IQ80321
total memory = 128 MB
avail memory = 113 MB
using 1228 buffers containing 6656 KB of memory
mainbus0 (root)
cpu0 at mainbus0: i80321 step A-0 (XScale core)
cpu0: DC enabled IC enabled WB enabled LABT
cpu0: 32KB/32B 32-way Instruction cache
cpu0: 32KB/32B 32-way write-back-locking Data cache
obio0 at mainbus0
com0 at obio0 addr 0xfe800000: ns16550a, working fifo
com0: console
iopxs0 at mainbus0: i80321 I/O Processor, acting as PCI host
iopxs0: configuring PCI bus
pci0 at iopxs0 bus 0
pci0: i/o space, memory space enabled, rd/line, rd/mult, wr/inv ok
wm0 at pci0 dev 4 function 0: Intel i82544 1000BASE-T Ethernet, rev. 2
wm0: interrupting at iop321 irq 27
wm0: Ethernet address 00:07:e9:03:38:40
makphy0 at wm0 phy 1: Marvell 88E1000 Gigabit PHY, rev. 0
makphy0: 10baseT, 10baseT-FDX, 100baseTX, 100baseTX-FDX, 1000baseT, 1000baseT-FDX,
clock: hz=100 stathz=0 profhz=0
boot device: <unknown>
root on wm0
nfs_boot: trying DHCP/BOOTP
nfs_boot: DHCP next-server: 192.168.0.1
nfs_boot: my_name=iq80321.lab.wasabisystems.com
nfs_boot: my_domain=wasabisystems.com
```

```
nfs_boot: my_addr=192.168.0.11
nfs_boot: my_mask=255.255.255.0
nfs_boot: gateway=192.168.0.254
root on 192.168.0.1:/export/client/iq80321
/etc/rc.conf is not configured.  Multiuser boot aborted.
Enter pathname of shell or RETURN for sh:
```

Post installation steps

Once you've got the operating system running, there are a few things you need to do in order to bring the system into a properly configured state. The most important steps are described below.

1. Configuring `/etc/rc.conf`

   If you or the installation software haven't done any configuration of `/etc/rc.conf` (**sysinst** usually will), the system will drop you into single user mode on first reboot with the message

   ```
   /etc/rc.conf is not configured. Multiuser boot aborted.
   ```

   and with the root file system (`/`) mounted read-only. When the system asks you to choose a shell, simply press `RETURN` to get to a `/bin/sh` prompt. If you are asked for a terminal type, respond with **vt220** (or whatever is appropriate for your terminal type) and press `RETURN`. You may need to type one of the following commands to get your delete key to work properly, depending on your keyboard:

   ```
   # stty erase '^h'
   # stty erase '^?'
   ```

   At this point, you need to configure at least one file in the `/etc` directory. You will need to mount your root file system read/write with:

   ```
   # /sbin/mount -u -w /
   ```

   Change to the `/etc` directory and take a look at the `/etc/rc.conf` file. Modify it to your tastes, making sure that you set `rc_configured=YES` so that your changes will be enabled and a multi-user boot can proceed. Default values for the various programs can be found in `/etc/defaults/rc.conf`, where some in-line documentation may be found. More complete documentation can be found in `rc.conf`(5).

   When you have finished editing `/etc/rc.conf`, type **exit** at the prompt to leave the single-user shell and continue with the multi-user boot.

   Other values that may need to be set in `/etc/rc.conf` for a networked environment are *hostname* and possibly *defaultroute*. You may also need to add an *ifconfig_int* for your ⟨int⟩ network interface, along the lines of

   ```
   ifconfig_fxp0="inet 192.0.2.123 netmask 255.255.255.0"
   ```

   or, if you have *myname.my.dom* in `/etc/hosts`:

   ```
   ifconfig_fxp0="inet myname.my.dom netmask 255.255.255.0"
   ```

   To enable proper hostname resolution, you will also want to add an `/etc/resolv.conf` file or (if you are feeling a little more adventurous) run `named`(8). See `resolv.conf`(5) or `named`(8) for more information. Instead of manually configuring network and naming service, DHCP can be used by setting `dhclient=YES` in `/etc/rc.conf`.

   Other files in `/etc` that may require modification or setting up include `/etc/mailer.conf`, `/etc/nsswitch.conf`, and `/etc/wscons.conf`.

2. Logging in

   After reboot, you can log in as `root` at the login prompt. Unless you've set a password in **sysinst**, there is no initial password. You should create an account for yourself (see below) and protect it and the

"root" account with good passwords. By default, root login from the network is disabled (even via `ssh`(1)). One way to become root over the network is to log in as a different user that belongs to group "wheel" (see `group`(5)) and use `su`(1) to become root.

3. Adding accounts

   Use the `useradd`(8) command to add accounts to your system. Do not edit `/etc/passwd` directly! See `vipw`(8) and `pwd_mkdb`(8) if you want to edit the password database.

4. The X Window System

   If you installed the X Window System, you may want to read the chapter about X in the NetBSD Guide:
   http://netbsd.org/docs/guide/en/chap-x.html

5. Installing third party packages

   If you wish to install any of the software freely available for UNIX-like systems you are strongly advised to first check the NetBSD package system, pkgsrc. pkgsrc automatically handles any changes necessary to make the software run on NetBSD. This includes the retrieval and installation of any other packages on which the software may depend.

   - More information on the package system is available at
     http://www.NetBSD.org/docs/software/packages.html
   - A list of available packages suitable for browsing is at
     ftp://ftp.NetBSD.org/pub/NetBSD/packages/pkgsrc/README.html
   - Precompiled binaries can be found at
     ftp://ftp.NetBSD.org/pub/pkgsrc/packages/NetBSD/
     usually in the `evbarm/6.0/All` subdir. If you installed `pkgin`(1) in the **`sysinst`** post-installation configuration menu, you can use it to automatically install binary packages over the network. Assuming that `/usr/pkg/etc/pkgin/repositories.conf` is correctly configured, you can install them with the following commands:

     ```
     # pkgin install tcsh
     # pkgin install bash
     # pkgin install perl
     # pkgin install apache
     # pkgin install kde
     # pkgin install firefox
     ...
     ```

     Note: Some mirror sites don't mirror the `/pub/pkgsrc` directory. If you would like to use such mirrors, you could also try the `/pub/NetBSD/packages/current-packages/NetBSD/evbarm/6.0/All` directory, which may have the same contents.

     The above commands will install the Tenex-csh and Bourne Again shells, the Perl programming language, Apache web server, KDE desktop environment and the Firefox web browser as well as all the packages they depend on.

   - If you did not install it from the **`sysinst`** post-installation configuration menu, the `pkgsrc`(7) framework for compiling packages can be obtained by retrieving the file
     ftp://ftp.NetBSD.org/pub/NetBSD/packages/pkgsrc.tar.gz
     It is typically extracted into `/usr/pkgsrc` (though other locations work fine) with the commands:

     ```
     # cd /usr
     # tar -zxpf pkgsrc.tar.gz
     ```

After extracting, see the `doc/pkgsrc.txt` file in the extraction directory (e.g., `/usr/pkgsrc/doc/pkgsrc.txt`) for more information.

6. Misc

   - Edit `/etc/mail/aliases` to forward root mail to the right place. Don't forget to run `newaliases`(1) afterwards.
   - The `/etc/postfix/main.cf` file will almost definitely need to be adjusted. If you prefer a different MTA, then install it using pkgsrc or by hand and adjust `/etc/mailer.conf`.
   - Edit `/etc/rc.local` to run any local daemons you use.
   - Many of the `/etc` files are documented in section 5 of the manual; so just invoking

     ```
     # man 5 filename
     ```

     is likely to give you more information on these files.

Upgrading a previously-installed NetBSD System

The easiest way to upgrade to NetBSD 6.0 is with binaries, and that is the method documented here.

To do the upgrade, you must have one form of boot media available. You must also have at least the **base** and **kern** binary distribution sets available. Finally, you must have sufficient disk space available to install the new binaries. Since files already installed on the system are overwritten in place, you only need additional free space for files which weren't previously installed or to account for growth of the sets between releases. If you have a few megabytes free on each of your root (`/`) and `/usr` partitions, you should have enough space.

Since upgrading involves replacing the kernel, boot blocks, and most of the system binaries, it has the potential to cause data loss. You are strongly advised to *back up* any important data on the NetBSD partition or on another operating system's partition on your disk before beginning the upgrade process.

The upgrade procedure is similar to an installation, but without the hard disk partitioning. **sysinst** will attempt to merge the settings stored in your `/etc` directory with the new version of NetBSD. Also, file systems are checked before unpacking the sets. Fetching the binary sets is done in the same manner as the installation procedure; refer to the installation part of the document for help.

After a new kernel has been copied to your hard disk, your machine is a complete NetBSD 6.0 system. However, that doesn't mean that you're finished with the upgrade process. You will probably want to update the set of device nodes you have in `/dev`. If you've changed the contents of `/dev` by hand, you will need to be careful about this, but if not, you can just cd into `/dev`, and run the command:

```
# sh MAKEDEV all
```

Finally, you will want to delete old binaries that were part of the version of NetBSD that you upgraded from and have since been removed from the NetBSD distribution.

Compatibility Issues With Previous NetBSD Releases

Users upgrading from previous versions of NetBSD may wish to bear the following problems and compatibility issues in mind when upgrading to NetBSD 6.0.

Note that **sysinst** will automatically invoke

```
postinstall fix
```

and thus all issues that are fixed by **postinstall** by default (see below) will be handled.

Issues affecting an upgrade from NetBSD 5.x releases

The pthread libraries from previous versions of NetBSD require that the `sysctl`(3) node `kern.no_sa_support` be set to `0`. This affects the following environments:

- Running a 5.0 kernel with an older userland.
- Running an older userland inside a chroot'ed environment on a 5.0 system.
- Running older statically linked pthread applications.

The 5.0 kernel defaults to `0` for `kern.no_sa_support`, which covers the first case. However, please note that a full installation of 5.0 (either from scratch or through an upgrade) will set `kern.no_sa_support` to 1 during the boot process. This means that for the last two cases, you will have to manually set `kern.no_sa_support` to `0`, using either the `sysctl`(8) command or through `sysctl.conf`(5).

The implementation of SHA2-HMAC in KAME_IPSEC as used in NetBSD-5 and before did not comply to current standards. FAST_IPSEC does, with the result that old and new systems cannot communicate over IPSEC, if one of the affected authentication algorithms (hmac_sha256, hmac_sha384, hmac_sha512) is used.

Issues affecting an upgrade from NetBSD 4.x releases

The following issues can generally be resolved by running *postinstall* with the **etc** set:

```
postinstall -s /path/to/etc.tgz check
postinstall -s /path/to/etc.tgz fix
```

Issues fixed by *postinstall*:

- Various files in `/etc` need upgrading. These include:
  - `/etc/defaults/*`
  - `/etc/mtree/*`
  - `/etc/daily`
  - `/etc/weekly`
  - `/etc/monthly`
  - `/etc/security`
  - `/etc/rc.subr`
  - `/etc/rc`
  - `/etc/rc.shutdown`
  - `/etc/rc.d/*`
  - `/etc/envsys.conf`

The following issues need to be resolved manually:

- The users '_httpd' and '_timedc' and the groups '_httpd' and '_timedc' need to be created.
- Unprivileged use of the `mount`(8) command now requires the *`nosuid`* and *`nodev`* options to be explicitly specified. Previously, these options were automatically enforced even if they were not explicitly specified.
- A number of things have been removed from the NetBSD 6.0 release. See the "Components removed from NetBSD" section near the beginning of this document for a list.

Using online NetBSD documentation

Documentation is available if you installed the manual distribution set. Traditionally, the "man pages" (documentation) are denoted by '`name(section)`'. Some examples of this are

- intro(1),
- man(1),
- apropos(1),
- passwd(1), and
- passwd(5).

The section numbers group the topics into several categories, but three are of primary interest: user commands are in section 1, file formats are in section 5, and administrative information is in section 8.

The *man* command is used to view the documentation on a topic, and is started by entering **man** [*section*] *topic*. The brackets [] around the section should not be entered, but rather indicate that the section is optional. If you don't ask for a particular section, the topic with the lowest numbered section name will be displayed. For instance, after logging in, enter

```
# man passwd
```

to read the documentation for passwd(1). To view the documentation for passwd(5), enter

```
# man 5 passwd
```

instead.

If you are unsure of what man page you are looking for, enter

```
# apropos subject-word
```

where *subject-word* is your topic of interest; a list of possibly related man pages will be displayed.

Administrivia

If you've got something to say, do so! We'd like your input. There are various mailing lists available via the mailing list server at majordomo@NetBSD.org. To get help on using the mailing list server, send mail to that address with an empty body, and it will reply with instructions. See **http://www.NetBSD.org/mailinglists/** for a web interface.

There are various mailing lists set up to deal with comments and questions about this release. Please send comments to: netbsd-comments@NetBSD.org.

To report bugs, use the send-pr(1) command shipped with NetBSD, and fill in as much information about the problem as you can. Good bug reports include lots of details.

Bugs also can be submitted and queried with the web interface at
http://www.NetBSD.org/support/send-pr.html

There are also port-specific mailing lists, to discuss aspects of each port of NetBSD. Use majordomo to find their addresses, or visit **http://www.NetBSD.org/mailinglists/**

If you're interested in doing a serious amount of work on a specific port, you probably should contact the 'owner' of that port (listed below).

If you'd like to help with this effort, and have an idea as to how you could be useful, send us mail or subscribe to: netbsd-users@NetBSD.org.

As a favor, please avoid mailing huge documents or files to these mailing lists. Instead, put the material you would have sent up for FTP or WWW somewhere, then mail the appropriate list about it, or, if you'd rather not do that, mail the list saying you'll send the data to those who want it.

Thanks go to

- The former members of UCB's Computer Systems Research Group, including (but not limited to):

  Keith Bostic
  Ralph Campbell
  Mike Karels
  Marshall Kirk McKusick

  for their work on BSD systems, support, and encouragement.
- The Internet Systems Consortium, Inc. for hosting the NetBSD FTP, CVS, AnonCVS, mail, mail archive, GNATS, SUP, Rsync and WWW servers.
- The Internet Research Institute in Japan for hosting the server which runs the CVSweb interface to the NetBSD source tree.
- The Luleå Academic Computer Society for providing the backup services server.
- The Columbia University Computer Science Department for hosting the NYC build cluster.
- The Western Washington University Computer Science Department for running the WWU build cluster.
- The many organizations that provide NetBSD mirror sites.
- Without CVS, this project would be impossible to manage, so our hats go off to Brian Berliner, Jeff Polk, and the various other people who've had a hand in making CVS a useful tool.
- We list the individuals and organizations that have made donations or loans of hardware and/or money, to support NetBSD development, and deserve credit for it at **http://www.NetBSD.org/donations/** (If you're not on that list and should be, tell us! We probably were not able to get in touch with you, to verify that you wanted to be listed.)
- Finally, we thank all of the people who've put sweat and tears into developing NetBSD since its inception in January, 1993. (Obviously, there are a lot more people who deserve thanks here. If you're one of them, and would like to be mentioned, tell us!)

We are...

(in alphabetical order)

The NetBSD core group:

Alan Barrett	apb@NetBSD.org
Alistair Crooks	agc@NetBSD.org
Matthew Green	mrg@NetBSD.org
Chuck Silvers	chs@NetBSD.org
Matt Thomas	matt@NetBSD.org
YAMAMOTO Takashi	yamt@NetBSD.org
Christos Zoulas	christos@NetBSD.org

The portmasters (and their ports):

Reinoud Zandijk	reinoud	**acorn32**
Matt Thomas	matt	**alpha**
Ignatios Souvatzis	is	**amiga**
Ignatios Souvatzis	is	**amigappc**
Noriyuki Soda	soda	**arc**
Julian Coleman	jdc	**atari**
Matthias Drochner	drochner	**cesfic**
Erik Berls	cyber	**cobalt**
Antti Kantee	pooka	**emips**
Simon Burge	simonb	**evbmips**
Steve Woodford	scw	**evbppc**
Izumi Tsutsui	tsutsui	**ews4800mips**
Izumi Tsutsui	tsutsui	**hp300**
Nick Hudson	skrll	**hp700**
Valeriy E. Ushakov	uwe	**hpcsh**
Matt Thomas	matt	**ibmnws**
Gavan Fantom	gavan	**iyonix**
Valeriy E. Ushakov	uwe	**landisk**
Izumi Tsutsui	tsutsui	**luna68k**
Scott Reynolds	scottr	**mac68k**
Michael Lorenz	macallan	**macppc**
Steve Woodford	scw	**mvme68k**
Steve Woodford	scw	**mvmeppc**
Matt Thomas	matt	**netwinder**
Izumi Tsutsui	tsutsui	**news68k**
Tim Rightnour	garbled	**ofppc**
Simon Burge	simonb	**pmax**
Tim Rightnour	garbled	**prep**
Tim Rightnour	garbled	**rs6000**
Tohru Nishimura	nisimura	**sandpoint**
Simon Burge	simonb	**sbmips**
Søren Jørvang	soren	**sgimips**
SAITOH Masanobu	msaitoh	**sh3**
Martin Husemann	martin	**sparc64**
Anders Magnusson	ragge	**vax**
NISHIMURA Takeshi	nsmrtks	**x68k**
Manuel Bouyer	bouyer	**xen**

The NetBSD 6.0 Release Engineering team:

Stephen Borrill	sborrill@NetBSD.org
Manuel Bouyer	bouyer@NetBSD.org
David Brownlee	abs@NetBSD.org
James Chacon	jmc@NetBSD.org
Julian Coleman	jdc@NetBSD.org
Alistair G. Crooks	agc@NetBSD.org
Håvard Eidnes	he@NetBSD.org
John Heasley	heas@NetBSD.org

Martin Husemann	martin@NetBSD.org
Soren Jacobsen	snj@NetBSD.org
Phil Nelson	phil@NetBSD.org
Jeremy C. Reed	reed@NetBSD.org
Jeff Rizzo	riz@NetBSD.org
SAITOH Masanobu	msaitoh@NetBSD.org

NetBSD Developers:

Nathan Ahlstrom	nra@NetBSD.org
Steve Allen	wormey@NetBSD.org
Jukka Andberg	jandberg@NetBSD.org
Julian Assange	proff@NetBSD.org
Lennart Augustsson	augustss@NetBSD.org
Zafer Aydogan	zafer@NetBSD.org
Christoph Badura	bad@NetBSD.org
Marc Balmer	mbalmer@NetBSD.org
Bang Jun-Young	junyoung@NetBSD.org
Dieter Baron	dillo@NetBSD.org
Robert V. Baron	rvb@NetBSD.org
Alan Barrett	apb@NetBSD.org
Grant Beattie	grant@NetBSD.org
Erik Berls	cyber@NetBSD.org
Hiroyuki Bessho	bsh@NetBSD.org
John Birrell	jb@NetBSD.org
Rafal Boni	rafal@NetBSD.org
Stephen Borrill	sborrill@NetBSD.org
Sean Boudreau	seanb@NetBSD.org
Manuel Bouyer	bouyer@NetBSD.org
Allen Briggs	briggs@NetBSD.org
Mark Brinicombe	mark@NetBSD.org
Aaron Brown	abrown@NetBSD.org
Andrew Brown	atatat@NetBSD.org
David Brownlee	abs@NetBSD.org
Jon Buller	jonb@NetBSD.org
Simon Burge	simonb@NetBSD.org
Robert Byrnes	byrnes@NetBSD.org
Pavel Cahyna	pavel@NetBSD.org
D'Arcy J.M. Cain	darcy@NetBSD.org
Taylor R. Campbell	riastradh@NetBSD.org
Daniel Carosone	dan@NetBSD.org
Dave Carrel	carrel@NetBSD.org
James Chacon	jmc@NetBSD.org
Mihai Chelaru	kefren@NetBSD.org
Aleksey Cheusov	cheusov@NetBSD.org
Bill Coldwell	billc@NetBSD.org
Julian Coleman	jdc@NetBSD.org
Marcus Comstedt	marcus@NetBSD.org
Jeremy Cooper	jeremy@NetBSD.org

Thomas Cort	tcort@NetBSD.org
Chuck Cranor	chuck@NetBSD.org
Alistair Crooks	agc@NetBSD.org
Johan Danielsson	joda@NetBSD.org
John Darrow	jdarrow@NetBSD.org
Jed Davis	jld@NetBSD.org
Matt DeBergalis	deberg@NetBSD.org
Arnaud Degroote	degroote@NetBSD.org
Rob Deker	deker@NetBSD.org
Chris G. Demetriou	cgd@NetBSD.org
Tracy Di Marco White	gendalia@NetBSD.org
Jaromír Dolecek	jdolecek@NetBSD.org
Andy Doran	ad@NetBSD.org
Roland Dowdeswell	elric@NetBSD.org
Steven Drake	sbd@NetBSD.org
Emmanuel Dreyfus	manu@NetBSD.org
Matthias Drochner	drochner@NetBSD.org
Jun Ebihara	jun@NetBSD.org
Håvard Eidnes	he@NetBSD.org
Jaime A Fournier	ober@NetBSD.org
Stoned Elipot	seb@NetBSD.org
Michael van Elst	mlelstv@NetBSD.org
Enami Tsugutomo	enami@NetBSD.org
Bernd Ernesti	veego@NetBSD.org
Erik Fair	fair@NetBSD.org
Gavan Fantom	gavan@NetBSD.org
Hauke Fath	hauke@NetBSD.org
Hubert Feyrer	hubertf@NetBSD.org
Jason R. Fink	jrf@NetBSD.org
Matt J. Fleming	mjf@NetBSD.org
Marty Fouts	marty@NetBSD.org
Liam J. Foy	liamjfoy@NetBSD.org
Matt Fredette	fredette@NetBSD.org
Thorsten Frueauf	frueauf@NetBSD.org
Castor Fu	castor@NetBSD.org
Makoto Fujiwara	mef@NetBSD.org
Ichiro Fukuhara	ichiro@NetBSD.org
Quentin Garnier	cube@NetBSD.org
Thomas Gerner	thomas@NetBSD.org
Simon J. Gerraty	sjg@NetBSD.org
Justin Gibbs	gibbs@NetBSD.org
Chris Gilbert	chris@NetBSD.org
Eric Gillespie	epg@NetBSD.org
Brian Ginsbach	ginsbach@NetBSD.org
Oliver V. Gould	ver@NetBSD.org
Paul Goyette	pgoyette@NetBSD.org
Michael Graff	explorer@NetBSD.org
Matthew Green	mrg@NetBSD.org
Andreas Gustafsson	gson@NetBSD.org

Ulrich Habel	rhaen@NetBSD.org
Jun-ichiro itojun Hagino	itojun@NetBSD.org
HAMAJIMA Katsuomi	hamajima@NetBSD.org
Adam Hamsik	haad@NetBSD.org
Juergen Hannken-Illjes	hannken@NetBSD.org
Charles M. Hannum	mycroft@NetBSD.org
Yorick Hardy	yhardy@NetBSD.org
Ben Harris	bjh21@NetBSD.org
Eric Haszlakiewicz	erh@NetBSD.org
John Hawkinson	jhawk@NetBSD.org
Emile Heitor	imil@NetBSD.org
John Heasley	heas@NetBSD.org
Lars Heidieker	para@NetBSD.org
Geert Hendrickx	ghen@NetBSD.org
René Hexel	rh@NetBSD.org
Iain Hibbert	plunky@NetBSD.org
Kouichirou Hiratsuka	hira@NetBSD.org
Michael L. Hitch	mhitch@NetBSD.org
Ádám Hóka	ahoka@NetBSD.org
Jachym Holecek	freza@NetBSD.org
David A. Holland	dholland@NetBSD.org
Christian E. Hopps	chopps@NetBSD.org
Daniel Horecki	morr@NetBSD.org
Ken Hornstein	kenh@NetBSD.org
Marc Horowitz	marc@NetBSD.org
Eduardo Horvath	eeh@NetBSD.org
Nick Hudson	skrll@NetBSD.org
Shell Hung	shell@NetBSD.org
Darran Hunt	darran@NetBSD.org
Martin Husemann	martin@NetBSD.org
Dean Huxley	dean@NetBSD.org
Love Hörnquist Åstrand	lha@NetBSD.org
Roland Illig	rillig@NetBSD.org
Bernardo Innocenti	bernie@NetBSD.org
Tetsuya Isaki	isaki@NetBSD.org
ITOH Yasufumi	itohy@NetBSD.org
IWAMOTO Toshihiro	toshii@NetBSD.org
Matthew Jacob	mjacob@NetBSD.org
Soren Jacobsen	snj@NetBSD.org
Lonhyn T. Jasinskyj	lonhyn@NetBSD.org
Darrin Jewell	dbj@NetBSD.org
Nicolas Joly	njoly@NetBSD.org
Søren Jørvang	soren@NetBSD.org
Takahiro Kambe	taca@NetBSD.org
Antti Kantee	pooka@NetBSD.org
Frank Kardel	kardel@NetBSD.org
KAWAMOTO Yosihisa	kawamoto@NetBSD.org
Min Sik Kim	minskim@NetBSD.org
KIYOHARA Takashi	kiyohara@NetBSD.org

Thomas Klausner	wiz@NetBSD.org
Klaus Klein	kleink@NetBSD.org
John Klos	jklos@NetBSD.org
Wayne Knowles	wdk@NetBSD.org
Takayoshi Kochi	kochi@NetBSD.org
Jonathan A. Kollasch	jakllsch@NetBSD.org
Radoslaw Kujawa	rkujawa@NetBSD.org
Jochen Kunz	jkunz@NetBSD.org
Martti Kuparinen	martti@NetBSD.org
Arnaud Lacombe	alc@NetBSD.org
Kevin Lahey	kml@NetBSD.org
David Laight	dsl@NetBSD.org
Johnny C. Lam	jlam@NetBSD.org
Guillaume Lasmayous	gls@NetBSD.org
Martin J. Laubach	mjl@NetBSD.org
Greg Lehey	grog@NetBSD.org
Ted Lemon	mellon@NetBSD.org
Christian Limpach	cl@NetBSD.org
Frank van der Linden	fvdl@NetBSD.org
Joel Lindholm	joel@NetBSD.org
Tonnerre Lombard	tonnerre@NetBSD.org
Mike Long	mikel@NetBSD.org
Michael Lorenz	macallan@NetBSD.org
Warner Losh	imp@NetBSD.org
Tomasz Luchowski	zuntum@NetBSD.org
Federico Lupi	federico@NetBSD.org
Brett Lymn	blymn@NetBSD.org
MAEKAWA Masahide	gehenna@NetBSD.org
Anders Magnusson	ragge@NetBSD.org
John Marino	marino@NetBSD.org
Roy Marples	roy@NetBSD.org
Cherry G. Mathew	cherry@NetBSD.org
David Maxwell	david@NetBSD.org
Gregory McGarry	gmcgarry@NetBSD.org
Dan McMahill	dmcmahill@NetBSD.org
Jared D. McNeill	jmcneill@NetBSD.org
Neil J. McRae	neil@NetBSD.org
Julio M. Merino Vidal	jmmv@NetBSD.org
Perry Metzger	perry@NetBSD.org
Luke Mewburn	lukem@NetBSD.org
Jean-Yves Migeon	jym@NetBSD.org
Brook Milligan	brook@NetBSD.org
Minoura Makoto	minoura@NetBSD.org
Simas Mockevicius	symka@NetBSD.org
der Mouse	mouse@NetBSD.org
Constantine A. Murenin	cnst@NetBSD.org
Joseph Myers	jsm@NetBSD.org
Tuomo Mäkinen	tjam@NetBSD.org
Zoltán Arnold NAGY	zoltan@NetBSD.org

Ken Nakata	kenn@NetBSD.org
Takeshi Nakayama	nakayama@NetBSD.org
Alexander Nasonov	alnsn@NetBSD.org
Phil Nelson	phil@NetBSD.org
John Nemeth	jnemeth@NetBSD.org
NISHIMURA Takeshi	nsmrtks@NetBSD.org
Tohru Nishimura	nisimura@NetBSD.org
NONAKA Kimihiro	nonaka@NetBSD.org
Takehiko NOZAKI	tnozaki@NetBSD.org
Tobias Nygren	tnn@NetBSD.org
OBATA Akio	obache@NetBSD.org
Jesse Off	joff@NetBSD.org
Tatoku Ogaito	tacha@NetBSD.org
OKANO Takayoshi	kano@NetBSD.org
Masaru Oki	oki@NetBSD.org
Ryo ONODERA	ryoon@NetBSD.org
Atsushi Onoe	onoe@NetBSD.org
Greg Oster	oster@NetBSD.org
Jonathan Perkin	sketch@NetBSD.org
Fredrik Pettai	pettai@NetBSD.org
Herb Peyerl	hpeyerl@NetBSD.org
Matthias Pfaller	matthias@NetBSD.org
Chris Pinnock	cjep@NetBSD.org
Adrian Portelli	adrianp@NetBSD.org
Chris Provenzano	proven@NetBSD.org
Mindaugas Rasiukevicius	rmind@NetBSD.org
Michael Rauch	mrauch@NetBSD.org
Marc Recht	recht@NetBSD.org
Darren Reed	darrenr@NetBSD.org
Jeremy C. Reed	reed@NetBSD.org
Jens Rehsack	sno@NetBSD.org
Antoine Reilles	tonio@NetBSD.org
Tyler R. Retzlaff	rtr@NetBSD.org
Scott Reynolds	scottr@NetBSD.org
Tim Rightnour	garbled@NetBSD.org
Jeff Rizzo	riz@NetBSD.org
Hans Rosenfeld	hans@NetBSD.org
Steve Rumble	rumble@NetBSD.org
Rumko	rumko@NetBSD.org
Jukka Ruohonen	jruoho@NetBSD.org
Blair J. Sadewitz	bjs@NetBSD.org
David Sainty	dsainty@NetBSD.org
SAITOH Masanobu	msaitoh@NetBSD.org
Kazuki Sakamoto	sakamoto@NetBSD.org
Curt Sampson	cjs@NetBSD.org
Wilfredo Sanchez	wsanchez@NetBSD.org
Ty Sarna	tsarna@NetBSD.org
SATO Kazumi	sato@NetBSD.org
Jan Schaumann	jschauma@NetBSD.org

Matthias Scheler	tron@NetBSD.org
Silke Scheler	silke@NetBSD.org
Karl Schilke (rAT)	rat@NetBSD.org
Amitai Schlair	schmonz@NetBSD.org
Konrad Schroder	perseant@NetBSD.org
Georg Schwarz	schwarz@NetBSD.org
Lubomir Sedlacik	salo@NetBSD.org
Christopher SEKIYA	sekiya@NetBSD.org
Reed Shadgett	dent@NetBSD.org
John Shannon	shannonjr@NetBSD.org
Tim Shepard	shep@NetBSD.org
Naoto Shimazaki	igy@NetBSD.org
Ryo Shimizu	ryo@NetBSD.org
Takao Shinohara	shin@NetBSD.org
Takuya SHIOZAKI	tshiozak@NetBSD.org
Daniel Sieger	dsieger@NetBSD.org
Chuck Silvers	chs@NetBSD.org
Thor Lancelot Simon	tls@NetBSD.org
Jeff Smith	jeffs@NetBSD.org
Noriyuki Soda	soda@NetBSD.org
Wolfgang Solfrank	ws@NetBSD.org
Jörg Sonnenberger	joerg@NetBSD.org
Ignatios Souvatzis	is@NetBSD.org
T K Spindler	dogcow@NetBSD.org
Matthew Sporleder	mspo@NetBSD.org
Bill Squier	groo@NetBSD.org
Adrian Steinmann	ast@NetBSD.org
Bill Studenmund	wrstuden@NetBSD.org
Kevin Sullivan	sullivan@NetBSD.org
Kimmo Suominen	kim@NetBSD.org
Grégoire Sutre	gsutre@NetBSD.org
Sergey Svishchev	shattered@NetBSD.org
Robert Swindells	rjs@NetBSD.org
Shin Takemura	takemura@NetBSD.org
TAMURA Kent	kent@NetBSD.org
Shin'ichiro TAYA	taya@NetBSD.org
Hasso Tepper	hasso@NetBSD.org
Matt Thomas	matt@NetBSD.org
Jason Thorpe	thorpej@NetBSD.org
Christoph Toshok	toshok@NetBSD.org
Greg Troxel	gdt@NetBSD.org
Tsubai Masanari	tsubai@NetBSD.org
Izumi Tsutsui	tsutsui@NetBSD.org
UCHIYAMA Yasushi	uch@NetBSD.org
Masao Uebayashi	uebayasi@NetBSD.org
Shuichiro URATA	ur@NetBSD.org
Valeriy E. Ushakov	uwe@NetBSD.org
Todd Vierling	tv@NetBSD.org
Aymeric Vincent	aymeric@NetBSD.org

Paul Vixie	vixie@NetBSD.org
Mike M. Volokhov	mishka@NetBSD.org
Krister Walfridsson	kristerw@NetBSD.org
Mark Weinem	weinem@NetBSD.org
Lex Wennmacher	wennmach@NetBSD.org
Leo Weppelman	leo@NetBSD.org
Assar Westerlund	assar@NetBSD.org
Frank Wille	phx@NetBSD.org
Nathan Williams	nathanw@NetBSD.org
Rob Windsor	windsor@NetBSD.org
Jim Wise	jwise@NetBSD.org
Colin Wood	ender@NetBSD.org
Steve Woodford	scw@NetBSD.org
YAMAMOTO Takashi	yamt@NetBSD.org
Yuji Yamano	yyamano@NetBSD.org
David Young	dyoung@NetBSD.org
Arnaud Ysmal	stacktic@NetBSD.org
Reinoud Zandijk	reinoud@NetBSD.org
S.P.Zeidler	spz@NetBSD.org
Tim Zingelman	tez@NetBSD.org
Christos Zoulas	christos@NetBSD.org

Legal Mumbo-Jumbo

All product names mentioned herein are trademarks or registered trademarks of their respective owners.

The following notices are required to satisfy the license terms of the software that we have mentioned in this document:

NetBSD is a registered trademark of The NetBSD Foundation, Inc.
This product includes software developed by the University of California, Berkeley and its contributors.
This product includes software developed by the NetBSD Foundation.
This product includes software developed by The NetBSD Foundation, Inc. and its contributors.
This product includes software developed for the NetBSD Project. See http://www.netbsd.org/ for information about NetBSD.
This product includes software developed by Intel Corporation and its contributors.
This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)
This product includes cryptographic software written by Eric Young (eay@mincom.oz.au)
This product includes software designed by William Allen Simpson.
This product includes software developed at Ludd, University of Lulea, Sweden and its contributors.
This product includes software developed at Ludd, University of Lulea.
This product includes software developed at the Information Technology Division, US Naval Research Laboratory.
This product includes software developed by David Jones and Gordon Ross
This product includes software developed by Hellmuth Michaelis and Joerg Wunsch
This product includes software developed by Internet Research Institute, Inc.
This product includes software developed by Leo Weppelman and Waldi Ravens.
This product includes software developed by Mika Kortelainen
This product includes software developed by Aaron Brown and Harvard University.
This product includes software developed by Adam Ciarcinski for the NetBSD project.
This product includes software developed by Adam Glass and Charles M. Hannum.
This product includes software developed by Adam Glass.
This product includes software developed by Advanced Risc Machines Ltd.
This product includes software developed by Alex Zepeda, and Colin Wood for the NetBSD Projet.
This product includes software developed by Alex Zepeda.
This product includes software developed by Amancio Hasty and Roger Hardiman
This product includes software developed by Berkeley Software Design, Inc.
This product includes software developed by Bill Paul.
This product includes software developed by Bodo Moeller. (If available, substitute umlauted o for oe)
This product includes software developed by Boris Popov.

This product includes software developed by Brini.
This product includes software developed by Bruce M. Simpson.
This product includes software developed by Causality Limited.
This product includes software developed by Charles Hannum.
This product includes software developed by Charles M. Hannum, by the University of Vermont and State Agricultural College and Garrett A. Wollman, by William F. Jolitz, and by the University of California, Berkeley, Lawrence Berkeley Laboratory, and its contributors.
This product includes software developed by Charles M. Hannum.
This product includes software developed by Christian E. Hopps, Ezra Story, Kari Mettinen, Markus Wild, Lutz Vieweg and Michael Teske.
This product includes software developed by Christian E. Hopps.
This product includes software developed by Christopher G. Demetriou for the NetBSD Project.
This product includes software developed by Christopher G. Demetriou.
This product includes software developed by Christos Zoulas.
This product includes software developed by Chuck Silvers.
This product includes software developed by Colin Wood for the NetBSD Project.
This product includes software developed by Colin Wood.
This product includes software developed by Daan Vreeken.
This product includes software developed by Daishi Kato
This product includes software developed by Daniel Widenfalk and Michael L. Hitch.
This product includes software developed by Daniel Widenfalk for the NetBSD Project.
This product includes software developed by Dean Huxley.
This product includes software developed by Eric S. Hvozda.
This product includes software developed by Eric S. Raymond
This product includes software developed by Eric Young (eay@@mincom.oz.au)
This product includes software developed by Eric Young (eay@cryptsoft.com)
This product includes software developed by Eric Young (eay@mincom.oz.au)
This product includes software developed by K. Kobayashi.
This product includes software developed by K. Kobayashi and H. Shimokawa.
This product includes software developed by Ezra Story and by Kari Mettinen.
This product includes software developed by Ezra Story, by Kari Mettinen and by Bernd Ernesti.
This product includes software developed by Ezra Story, by Kari Mettinen, Michael Teske and by Bernd Ernesti.
This product includes software developed by Ezra Story, by Kari Mettinen, and Michael Teske.
This product includes software developed by Ezra Story.
This product includes software developed by Florian Stoehr.
This product includes software developed by Frank van der Linden for the NetBSD Project.
This product includes software developed by Gardner Buchanan.
This product includes software developed by Garrett D'Amore.
This product includes software developed by Gary Thomas.
This product includes software developed by Gordon Ross
This product includes software developed by Harvard University and its contributors.
This product includes software developed by Harvard University.
This product includes software developed by Henrik Vestergaard Draboel.
This product includes software developed by Herb Peyerl.
This product includes software developed by Hidetoshi Shimokawa.
This product includes software developed by Ian W. Dall.
This product includes software developed by Ignatios Souvatzis for the NetBSD Project.
This product includes software developed by Internet Initiative Japan Inc.
This product includes software developed by James R. Maynard III.
This product includes software developed by Jason L. Wright
This product includes software developed by Jason R. Thorpe for And Communications, http://www.and.com/
This product includes software developed by Joachim Koenig-Baltes.
This product includes software developed by Jochen Pohl for The NetBSD Project.
This product includes software developed by Joerg Wunsch
This product includes software developed by John Birrell.
This product includes software developed by John P. Wittkoski.
This product includes software developed by John Polstra.
This product includes software developed by Jonathan R. Stone for the NetBSD Project.
This product includes software developed by Jonathan Stone and Jason R. Thorpe for the NetBSD Project.
This product includes software developed by Jonathan Stone.
This product includes software developed by Julian Highfield.
This product includes software developed by Kazuhisa Shimizu.
This product includes software developed by Kazuki Sakamoto.
This product includes software developed by Kenneth Stailey.
This product includes software developed by Kiyoshi Ikehara.
This product includes software developed by Klaus Burkert,by Bernd Ernesti, by Michael van Elst, and by the University of California, Berkeley and its contributors.

This product includes software developed by LAN Media Corporation and its contributors.
This product includes software developed by Lloyd Parkes.
This product includes software developed by Lutz Vieweg.
This product includes software developed by MINOURA Makoto, Takuya Harakawa.
This product includes software developed by Marc Horowitz.
This product includes software developed by Marcus Comstedt.
This product includes software developed by Mark Brinicombe for the NetBSD project.
This product includes software developed by Mark Brinicombe.
This product includes software developed by Mark Tinguely and Jim Lowe
This product includes software developed by Markus Wild.
This product includes software developed by Masanobu Saitoh.
This product includes software developed by Masaru Oki.
This product includes software developed by Matthew Fredette.
This product includes software developed by Michael Smith.
This product includes software developed by Mike Pritchard.
This product includes software developed by Mike Pritchard and contributors.
This product includes software developed by Minoura Makoto.
This product includes software developed by Niels Provos.
This product includes software developed by Niklas Hallqvist, Brandon Creighton and Job de Haas.
This product includes software developed by Niklas Hallqvist.
This product includes software developed by Paul Kranenburg.
This product includes software developed by Paul Mackerras.
This product includes software developed by Per Fogelstrom
This product includes software developed by Peter Galbavy.
This product includes software developed by Phase One, Inc.
This product includes software developed by Philip A. Nelson.
This product includes software developed by RiscBSD.
This product includes software developed by Roar Thronæs.
This product includes software developed by Rodney W. Grimes.
This product includes software developed by Roger Hardiman
This product includes software developed by Rolf Grossmann.
This product includes software developed by Ross Harvey for the NetBSD Project.
This product includes software developed by Ross Harvey.
This product includes software developed by Scott Bartram.
This product includes software developed by Scott Stevens.
This product includes software developed by Shingo WATANABE.
This product includes software developed by Softweyr LLC, the University of California, Berkeley, and its contributors.
This product includes software developed by Stephan Thesing.
This product includes software developed by Steven M. Bellovin.
This product includes software developed by Takashi Hamada.
This product includes software developed by Takumi Nakamura.
This product includes software developed by Tatoku Ogaito for the NetBSD Project.
This product includes software developed by Terrence R. Lambert.
This product includes software developed by TooLs GmbH.
This product includes software developed by Trimble Navigation, Ltd.
This product includes software developed by WIDE Project and its contributors.
This product includes software developed by Waldi Ravens.
This product includes software developed by Wasabi Systems for Zembu Labs, Inc. http://www.zembu.com/
This product includes software developed by Winning Strategies, Inc.
This product includes software developed by Wolfgang Solfrank.
This product includes software developed by Yasushi Yamasaki.
This product includes software developed by Yen Yen Lim and North Dakota State University.
This product includes software developed by Zembu Labs, Inc.
This product includes software developed by the Alice Group.
This product includes software developed by the Center for Software Science at the University of Utah.
This product includes software developed by the Charles D. Cranor, Washington University, University of California, Berkeley and its contributors.
This product includes software developed by the Computer Systems Engineering Group at Lawrence Berkeley Laboratory.
This product includes software developed by the David Muir Sharnoff.
This product includes software developed by the Harvard University and its contributors.
This product includes software developed by the Network Research Group at Lawrence Berkeley Laboratory.
This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.OpenSSL.org/)
This product includes software developed by the PocketBSD project and its contributors.
This product includes software developed by the RiscBSD kernel team
This product includes software developed by the RiscBSD team.
This product includes software developed by the SMCC Technology Development Group at Sun Microsystems, Inc.

This product includes software developed by the University of California, Berkeley and its contributors, as well as the Trustees of Columbia University.
This product includes software developed by the University of California, Lawrence Berkeley Laboratory and its contributors.
This product includes software developed by the University of California, Lawrence Berkeley Laboratory.
This product includes software developed by the University of Illinois at Urbana and their contributors.
This product includes software developed by the Urbana-Champaign Independent Media Center.
This product includes software developed by the University of Vermont and State Agricultural College and Garrett A. Wollman.
This product includes software developed by the University of Vermont and State Agricultural College and Garrett A. Wollman, by William F. Jolitz, and by the University of California, Berkeley, Lawrence Berkeley Laboratory, and its contributors.
This product includes software developed for the FreeBSD project
This product includes software developed for the NetBSD Project by Bernd Ernesti.
This product includes software developed for the NetBSD Project by Christopher G. Demetriou.
This product includes software developed for the NetBSD Project by Emmanuel Dreyfus.
This product includes software developed for the NetBSD Project by Frank van der Linden
This product includes software developed for the NetBSD Project by Ignatios Souvatzis.
This product includes software developed for the NetBSD Project by Jason R. Thorpe.
This product includes software developed for the NetBSD Project by John M. Vinopal.
This product includes software developed by Kyma Systems.
This product includes software developed for the NetBSD Project by Kyma Systems LLC.
This product includes software developed for the NetBSD Project by Matthias Drochner.
This product includes software developed for the NetBSD Project by Perry E. Metzger.
This product includes software developed for the NetBSD Project by Scott Bartram and Frank van der Linden
This product includes software developed for the NetBSD Project by Allegro Networks, Inc., and Wasabi Systems, Inc.
This product includes software developed for the NetBSD Project by Genetec Corporation.
This product includes software developed for the NetBSD Project by Jonathan Stone.
This product includes software developed for the NetBSD Project by Piermont Information Systems Inc.
This product includes software developed for the NetBSD Project by SUNET, Swedish University Computer Network.
This product includes software developed for the NetBSD Project by Shigeyuki Fukushima.
This product includes software developed for the NetBSD Project by Wasabi Systems, Inc.
This product includes software developed under OpenBSD by Per Fogelstrom Opsycon AB for RTMX Inc, North Carolina, USA.
This product includes software developed under OpenBSD by Per Fogelstrom.
This software is a component of "386BSD" developed by William F. Jolitz, TeleMuse.
This software was developed by Holger Veit and Brian Moore for use with "386BSD" and similar operating systems. "Similar operating systems" includes mainly non-profit oriented systems for research and education, including but not restricted to "NetBSD", "FreeBSD", "Mach" (by CMU).
This software includes software developed by the Computer Systems Laboratory at the University of Utah.
This product includes software developed by Computing Services at Carnegie Mellon University (http://www.cmu.edu/computing/).
This product includes software developed by Marshall M. Midden.
This product includes software developed or owned by Caldera International, Inc.
The Institute of Electrical and Electronics Engineers and The Open Group, have given us permission to reprint portions of their documentation.

In the following statement, the phrase ‘‘this text’’ refers to portions of the system documentation.

Portions of this text are reprinted and reproduced in electronic form in NetBSD, from IEEE Std 1003.1, 2004 Edition, Standard for Information Technology -- Portable Operating System Interface (POSIX), The Open Group Base Specifications Issue 6, Copyright (C) 2001-2004 by the Institute of Electrical and Electronics Engineers, Inc and The Open Group. In the event of any discrepancy between these versions and the original IEEE and The Open Group Standard, the original IEEE and The Open Group Standard is the referee document.

The original Standard can be obtained online at http://www.opengroup.org/unix/online.html.

This notice shall appear on any product containing this material

This product includes software developed by Advanced Risc Machines Ltd.
This product includes software developed by Microsoft.
This product includes software developed by the RiscBSD kernel team.
This product includes software developed by Scott Stevens.

The End